

TIREMAAX® CP TIRE INFLATION SYSTEM INDICATOR LAMP STATUS GUIDE

Indicator Lamp Status	Possible System Condition
Continuously on for more than 10 minutes*	<ul style="list-style-type: none"> One or more tires low Substantial air line leak
<p>To verify functionality of the indicator lamp, completely open the petcock at the control box delivery line and inspect the lamp for proper operation.</p> <p>NOTE: For TIREMAAX® CP to function properly, the supply air tank pressure must be higher than the target tire pressure.</p> <p>* The TIREMAAX CP system uses the trailer blue circuit for power. Some early model tractors do not power this circuit, resulting in no power to the TIREMAAX CP indicator lamp. Refer to Hendrickson publication L995, TIREMAAX CP Installation, Service and Troubleshooting Procedures, for complete system details.</p>	

Trailer Suspension Systems
2070 Industrial Place SE
Canton, OH 44707-2641 USA
866.RIDEAIR (743.3247)
330.489.0045
Fax 800.696.4416



Trailer Suspension Systems
250 Chrysler Drive, Unit #3
Brampton, ON Canada L6S 6B6
905.789.1030
Fax 905.789.1033

L982 08-07 ECN 15922

www.hendrickson-intl.com

Printed in the United States of America.

© 2007 Hendrickson USA, L.L.C. (U.S. Rights). Hendrickson International Corporation (Rights Outside U.S.). All Rights Reserved.

MANUALLY CHECKING TIRE PRESSURE

⚠WARNING: To prevent injury, always wear eye protection when maintaining or servicing the TIREMAAX® CP system.

NOTE: Check valves in the tire hoses help prevent tire pressure loss when a tire hose is removed. You may experience a slight burst of air when the hose is disconnected.

To manually check tire pressure:

1. Disconnect tire hose from tee or elbow at hubcap.
2. Use a conventional gage to measure tire pressure at hose end.
3. Reattach and firmly hand-tighten tire hose.

⚠CAUTION: Do not overtighten tire hose or the internal seal may be damaged. Ensure tire hoses are not stretched or rubbing on the wheel.

