

# HTECHNICAL PROCEDURE

SOFTEK® Front Suspension with STEERTEK™ NXT Axle for Workhorse W56 Medium-duty Electric Step Vans

**SUBJECT:** Service Instructions

**LIT NO**: 17730-356

**DATE**: June 2024 **REVISION**: A

	n	$\sim$ r	$\boldsymbol{\alpha}$	NTEI	TTO.
-11/	١к	116		$\mathbf{n} + \mathbf{n} = \mathbf{n}$	W 1
	ч.	VI.	10701		VI 100

Section 1	Introduction		Toe Setting
Section 2	Product Description 2		Leaf Spring Eye Re-torque
Section 3	Important Safety Notice 4		Wheel End and Hydraulic Disc Brake
Section 4	Parts Lists		Assemblies and Components 31
Section 5	Special Tools	Section 9	Component Replacement
Section 6	Towing Procedure		Fasteners
Section 7	Preventive Maintenance		Front Leaf Spring Eye Bushings 32
	Hendrickson Recommended Inspection		Frame Hanger32
	Intervals		Rear Shackle Bracket33
	Component Inspection		Rubber Axle Stop
	Lubrication Intervals		Shock Absorber
	Kingpin Lubrication		Leaf Spring Assembly
	Tie Rod Ends15		STEERTEK NXT Axle37
	Clamp Group18		Steering Knuckle Disassembly40
	Kingpin Bushing		Kingpin Preparation and Measurement 41
	Steering Knuckle		Kingpin Bushing
	Shock Absorbers		Steering Knuckle Assembly
	Visual Tire Inspection		Tie Rod End and Cross Tube 48
	Wheel End and Hydraulic Disc Brake Assemblies and Components 23		Wheel End and Hydraulic Disc Brake Assemblies and Components 49
Section 8	Alignment & Adjustments	Section 10	Troubleshooting Guide50
	Alignment Definitions	Section 11	Torque Specifications
	Inspection Prior to Alignment 26	Section 12	Front Wheel Alignment Specifications 55
	Front Wheel Alignment 26	Section 13	Reference Material
	Steering Stop28		





# SECTION 1 Introduction

This publication is intended to acquaint and assist maintenance personnel in the preventive maintenance, service, repair and rebuild of Hendrickson SOFTEK® front mechanical suspension with fabricated STEERTEK NXT axle systems installed on applicable Workhorse W56 Electric Step Vans.

**NOTE** 

Use only Hendrickson Genuine parts for servicing this suspension system.

It is important to read and understand this entire Technical Procedure publication and all work instructions and safety related information provided by the vehicle manufacturer prior to performing any maintenance, service, repair, or rebuild of this product. The information in this publication contains parts lists, safety information, product specifications, features, proper maintenance, service, repair, and rebuild instructions for the SOFTEK suspension with the STEERTEK NXT axle.

Hendrickson reserves the right to make changes and improvements to its products and publications at any time. Contact Hendrickson Tech Services for information on the latest version of this manual at 855-743-3733 (toll-free U.S. and Canada), 630-910-2800 (outside U.S. and Canada) or e-mail: wdtechservices@hendrickson-intl.com.

The latest revision of this publication is also available online at www.hendrickson-intl.com.

# SECTION 2 Product Description


**SOFTEK Integrated Front Suspension and Steer Axle System** — that works to form an integrated torsion system. Utilizing a system approach, Hendrickson has engineered and optimized the following components to form a system delivering ride, stability and handling characteristics with reduced weight and maintenance.

- Leaf spring assembly With its innovative design, the leaf spring provides superior roll stability, performance and a soft ride. Durable rubber bushings are greaseless and only require periodic inspections.
- **Shock absorbers** SOFTEK utilizes premium shocks that have been tested and tuned specifically for the suspension system.
- Frame brackets Optimized design delivers weight reduction and proven durability.

**STEERTEK NXT Front Steer Axle** — The fabricated box-shaped cross section resists horizontal, vertical and twisting forces more effectively than traditional I beam axles to improve handling.

- Axle Clamp Group The Clamp Group consists of the top pad, U-bolts, washers, and locknuts.
- Integrated Axle Seats Improve ground clearance, reduce part count, and simplify assembly.
- Adjustable Tie Rod To help maximize tire life, the tie rod easily adjusts toe-in/out.
- Steering Knuckles The steering and tie rod arms are integrated for increased strength and reduced weight. The unique steering knuckle packaging delivers up to a maximum of 50° wheel cut. The two piece knuckle design makes replacing the kingpin bushings easier by eliminating the need to remove the kingpins. Premium kingpin bushings and seals provide enhanced protection from the elements to improve bushing life.





# **TECHNICAL NOTES**

- 1. The SOFTEK system with STEERTEK NXT axle is approved for applications rated up to 8K pounds capacity.
- SOFTEK is approved for on-highway use; other applications must be pre-approved by Hendrickson Sales Engineering. System capacity rating for the suspension represents maximum loads on tires at ground level.
- 3. The STEERTEK NXT axle is available with 64.25" kingpin intersection (KPI).
- 4. SOFTEK suspension weight (275 pounds) includes frame and shackle bracket assemblies, steel leaf springs, bushings, shocks, upper shock brackets and axle clamp group.
- 5. STEERTEK NXT axle weight (525 pounds) includes the axle beam, knuckle / steering arm assemblies, tie rod assembly and wheel end components.
- 6. SOFTEK is integral to and available exclusively with the STEERTEK NXT axle. This system is anti-lock braking system (ABS) ready. STEERTEK NXT is compatible with most industry standard wheel ends and brakes. Contact vehicle manufacturer for more information.
- 7. The STEERTEK NXT axle product identification is etched on the center front of the axle beam (See Figure 2-2) providing the following information:
  - Axle part number: Identifies the features of the axle beam.
  - Axle assembly number: Identifies the complete assembly, which includes the steering knuckles, bracket assemblies and tie rod assemblies

**FIGURE 2-2** Front view of the axle showing approximate location of product identification.



17730-356 3 Product Description



# **SECTION 3**

# **Important Safety Notice**

Proper maintenance, service and repair is important to the reliable operation of the suspension. The procedures recommended by Hendrickson and described in this technical publication are methods of performing such maintenance, service and repair.

The warnings and cautions should be read carefully to help prevent personal injury and to assure that proper methods are used. Improper maintenance, service or repair may damage the vehicle, cause personal injury, render the vehicle unsafe in operation, or void manufacturer's warranty.

Failure to follow the safety precautions in this manual can result in personal injury and/or property damage. Carefully read and understand all safety related information within this publication, on all decals and all such materials provided by the vehicle manufacturer before conducting any maintenance, service or repair.

### **EXPLANATION OF SIGNAL WORDS**

Hazard "Signal Words" (Danger-Warning-Caution) appear in various locations throughout this publication. Information accented by one of these signal words must be observed to help minimize the risk of personal injury to service personnel, or possibility of improper service methods which may damage the vehicle or render it unsafe.

This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

Additional 'Notes' or 'Service Hints' are utilized to emphasize areas of procedural importance and provide suggestions for ease of repair. The following definitions indicate the use of these signal words as they appear throughout the publication.



INDICATES AN IMMINENTLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, WILL RESULT IN SERIOUS INJURY OR DEATH.



INDICATES A POTENTIAL HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, CAN RESULT IN SERIOUS INJURY OR DEATH.



INDICATES A POTENTIAL HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, MAY RESULT IN MINOR OR MODERATE INJURY, OR PROPERTY DAMAGE.

NOTE

An operating procedure, practice condition, etc. which is essential to emphasize.

### **SERVICE HINT**

A helpful suggestion, which will make the servicing being performed a little easier and/or faster.

Also note that particular service operations may require the use of special tools designed for specific purposes. These special tools can be found in the Special Tools section of this publication.



The torque symbol alerts you to tighten fasteners to a specified torque value. Refer to Torque Specifications section of this publication.



# **SAFETY PRECAUTIONS**



### **FASTENERS**

DISCARD USED FASTENERS. ALWAYS USE NEW FASTENERS TO COMPLETE A REPAIR. FAILURE TO DO SO COULD RESULT IN FAILURE OF THE PART, OR MATING COMPONENTS, LOSS OF VEHICLE CONTROL, POSSIBLE PERSONAL INJURY, OR PROPERTY DAMAGE.

LOOSE OR OVER TORQUED FASTENERS CAN CAUSE COMPONENT DAMAGE, LOSS OF VEHICLE CONTROL, PROPERTY DAMAGE, OR SEVERE PERSONAL INJURY. MAINTAIN CORRECT TORQUE VALUE AT ALL TIMES. CHECK TORQUE VALUES ON A REGULAR BASIS AS SPECIFIED, USING A TORQUE WRENCH THAT IS REGULARLY CALIBRATED. TORQUE VALUES SPECIFIED IN THIS TECHNICAL PUBLICATION ARE FOR HENDRICKSON SUPPLIED FASTENERS ONLY. IF NON-HENDRICKSON FASTENERS ARE USED, FOLLOW THE TORQUE SPECIFICATIONS LISTED IN THE VEHICLE MANUFACTURER'S SERVICE MANUAL.



### LOAD CAPACITY

ADHERE TO THE PUBLISHED CAPACITY RATINGS FOR THE SUSPENSIONS. ADD-ON AXLE ATTACHMENTS AND OTHER LOAD TRANSFERRING DEVICES CAN INCREASE THE SUSPENSION LOAD ABOVE THE RATED AND APPROVED CAPACITIES WHICH COULD RESULT IN FAILURE AND LOSS OF VEHICLE CONTROL, POSSIBLY CAUSING PERSONAL INJURY OR PROPERTY DAMAGE.



### SUPPORT THE VEHICLE PRIOR TO SERVICING

PLACE THE VEHICLE ON A LEVEL FLOOR AND CHOCK THE WHEELS TO PREVENT THE VEHICLE FROM MOVING OR ROLLING. DO NOT WORK AROUND OR UNDER A RAISED VEHICLE SUPPORTED BY ONLY A FLOOR JACK. ALWAYS SUPPORT A RAISED VEHICLE WITH RIGID SAFETY STANDS. FAILURE TO DO SO CAN CAUSE SERIOUS PERSONAL INJURY OR DAMAGE TO EQUIPMENT.



### **PROCEDURES AND TOOLS**

A TECHNICIAN USING A SERVICE PROCEDURE OR TOOL WHICH HAS NOT BEEN RECOMMENDED BY HENDRICKSON MUST FIRST SATISFY THEMSELVES THAT NEITHER THEIR SAFETY NOR THE VEHICLE'S SAFETY WILL BE JEOPARDIZED BY THE METHOD OR TOOL SELECTED. INDIVIDUALS DEVIATING IN ANY MANNER FROM THE INSTRUCTIONS PROVIDED ASSUME ALL RISKS OF POTENTIAL PERSONAL INJURY OR DAMAGE TO EQUIPMENT INVOLVED.



### PERSONNEL PROTECTIVE EQUIPMENT

ALWAYS WEAR PROPER EYE PROTECTION AND OTHER REQUIRED PERSONAL PROTECTIVE EQUIPMENT TO HELP PREVENT PERSONAL INJURY WHEN PERFORMING VEHICLE MAINTENANCE, REPAIR OR SERVICE.



### MODIFYING COMPONENTS

DO NOT MODIFY OR REWORK PARTS WITHOUT AUTHORIZATION FROM HENDRICKSON. DO NOT SUBSTITUTE REPLACEMENT COMPONENTS NOT AUTHORIZED BY HENDRICKSON. USE OF MODIFIED, REWORKED, SUBSTITUTE OR REPLACEMENT PARTS NOT AUTHORIZED BY HENDRICKSON MAY NOT MEET HENDRICKSON'S SPECIFICATIONS, AND CAN RESULT IN FAILURE OF THE PART, LOSS OF VEHICLE CONTROL, POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE, AND WILL VOID ANY APPLICABLE WARRANTIES. USE ONLY HENDRICKSON AUTHORIZED REPLACEMENT PARTS.



### **TORCH/WELDING**

DO NOT USE A CUTTING TORCH TO REMOVE ANY ATTACHING FASTENERS. THE USE OF HEAT ON SUSPENSION COMPONENTS WILL ADVERSELY AFFECT THE STRENGTH OF THESE PARTS. A COMPONENT DAMAGED IN THIS MANNER CAN RESULT IN THE LOSS OF VEHICLE CONTROL AND POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE.

EXERCISE EXTREME CARE WHEN HANDLING OR PERFORMING MAINTENANCE IN THE AREA OF THE MAIN SUPPORT MEMBER. DO NOT CONNECT ARC WELDING GROUND LINE TO THE MAIN SUPPORT MEMBER. DO NOT STRIKE AN ARC WITH THE ELECTRODE ON THE MAIN SUPPORT MEMBER. DO NOT USE HEAT NEAR THE MAIN SUPPORT MEMBER ASSEMBLY. DO NOT NICK OR GOUGE THE MAIN SUPPORT MEMBER. SUCH IMPROPER ACTIONS CAN DAMAGE TO THE MAIN SUPPORT MEMBER ASSEMBLY AND CAN CAUSE AND CAN CAUSE LOSS OF VEHICLE CONTROL AND POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE.





### SHOCK ABSORBERS

THE SHOCK ABSORBERS ARE THE REBOUND TRAVEL STOPS FOR THE SUSPENSION. ANYTIME THE AXLE ON SOFTEK SUSPENSION IS SUSPENDED IT IS MANDATORY THAT THE SHOCK ABSORBERS REMAIN CONNECTED. FAILURE TO DO SO CAN CAUSE THE AIR SPRINGS TO SEPARATE FROM THE PISTON AND RESULT IN PREMATURE AIR SPRING FAILURE. REPLACEMENT OF SHOCK ABSORBERS WITH NON-HENDRICKSON PARTS CAN ALTER THE REBOUND TRAVEL OF THE SUSPENSION.



### **UNAUTHORIZED REPAIR OR RECONDITIONING**

THE REPAIR OR RECONDITIONING OF SUSPENSION OR AXLE COMPONENTS IS NOT ALLOWED AS SHOWN ON LABEL IN FIGURE 3-1. ANY AXLE COMPONENTS FOUND TO BE DAMAGED OR OUT OF SPECIFICATIONS MUST BE REPLACED. ALL MAJOR COMPONENTS ARE HEAT TREATED AND TEMPERED. THE COMPONENTS CANNOT BE BENT, WELDED, HEATED, OR REPAIRED WITHOUT REDUCING THE STRENGTH OR LIFE OF THE COMPONENT. FAILURE TO FOLLOW THESE GUIDELINES CAN CAUSE LOSS OF VEHICLE CONTROL, POSSIBLE PERSONAL INJURY, DEATH, OR PROPERTY DAMAGE AND WILL VOID APPLICABLE WARRANTIES.



### STEERTEK NXT AXLE

UNAUTHORIZED WELDING OR MODIFICATIONS CAN CAUSE CRACKS OR OTHER AXLE STRUCTURAL DAMAGE AND RESULT IN LOSS OF VEHICLE CONTROL, SEVERE PERSONAL INJURY OR DEATH. DO NOT BEND, WELD OR MODIFY AXLE WITHOUT AUTHORIZATION FROM HENDRICKSON TRUCK COMMERCIAL VEHICLE SYSTEMS.



### DAMAGED AXLE COMPONENTS

IF A VEHICLE EQUIPPED WITH A STEERTEK NXT AXLE IS INVOLVED IN A CRASH, THE AXLE STEER KNUCKLES MUST BE DISASSEMBLED AND A THOROUGH INSPECTION OF THE AXLE MUST BE PERFORMED NOTING THE CONDITION OF THE AXLE BEAM, KINGPINS, AND KNUCKLE ASSEMBLIES, INCLUDING THE AREAS OF AXLE TO KINGPIN INTERFACE FOR ANY DAMAGE, GAPS, KINGPIN MOVEMENT OR PLAY. IF ANY COMPONENT APPEARS DAMAGED, OR THE KINGPINS APPEAR TO CONTAIN ANY DAMAGE, GAPS, MOVEMENT OR PLAY, THE COMPLETE AXLE ASSEMBLY MUST BE REPLACED.

IN ADDITION, IN THE EVENT A CRASH RESULTS IN EXCESSIVE SIDE LOAD DAMAGE TO ADJACENT PARTS, SUCH AS A BENT WHEEL, HUB, OR SPINDLE, IT IS STRONGLY RECOMMENDED TO REPLACE THE COMPLETE AXLE ASSEMBLY.

CONTACT HENDRICKSON TECHNICAL SERVICES WITH ANY QUESTIONS. FAILURE TO REPLACE ANY DAMAGED COMPONENTS CAN CAUSE LOSS OF VEHICLE CONTROL, POSSIBLE PERSONAL INJURY, DEATH, OR PROPERTY DAMAGE AND WILL VOID ANY APPLICABLE WARRANTIES.



### **AXLE CAMBER IS NOT ADJUSTABLE**

DO NOT CHANGE THE AXLE CAMBER ANGLE OR BEND THE AXLE BEAM. BENDING THE AXLE BEAM TO CHANGE THE CAMBER ANGLE CAN DAMAGE THE AXLE AND REDUCE AXLE STRENGTH, WILL VOID WARRANTY, AS APPLICABLE AND CAN CAUSE LOSS OF VEHICLE CONTROL, POSSIBLY CAUSING PERSONAL INJURY OR PROPERTY DAMAGE.



### **AXLE KINGPINS**

STEERTEK NXT IS A UNIQUE AXLE, IN THAT THE KINGPIN IS CRYOGENICALLY INSTALLED IN THE AXLE. THE KINGPIN IS A NON-REPLACEABLE COMPONENT OF THE AXLE ASSEMBLY. DO NOT TRY TO REMOVE THE KINGPIN. IF THE KINGPIN OR ADJACENT MATING SURFACE SHOW SIGNS OF DAMAGE OR MOVEMENT, DO NOT OPERATE THE VEHICLE AND IMMEDIATELY CONTACT THE HENDRICKSON TECH SERVICES DEPARTMENT.



### **IMPROPER JACKING METHOD**

IMPROPER JACKING METHOD CAN CAUSE STRUCTURAL DAMAGE AND RESULT IN LOSS OF VEHICLE CONTROL, SEVERE PERSONAL INJURY OR DEATH. DO NOT USE AXLE BEAM OUTBOARD OF AXLE SEATS. REFER TO VEHICLE MANUFACTURER FOR PROPER JACKING INSTRUCTIONS, SEE FIGURE 3-1.






### **AXLE SPRING SEATS**

THE INTEGRATED AXLE SPRING SEATS ON THE STEERTEK NXT AXLE ARE NON-SERVICEABLE. UNAUTHORIZED TAMPERING OF INTEGRATED AXLE SPRING SEATS CAN CAUSE COMPONENT AND STRUCTURAL DAMAGE AND RESULT IN LOSS OF VEHICLE CONTROL, SEVERE PERSONAL INJURY OR DEATH, PROPERTY DAMAGE, AND WILL VOID ANY APPLICABLE WARRANTY. DO NOT REMOVE, MODIFY OR REPLACE INTEGRATED AXLE SPRING SEAT OR FASTENERS. SEE FIGURE 3-1.

NOTE: REPLACE ANY SAFETY DECALS THAT ARE FADED, TORN, MISSING, ILLEGIBLE, OR OTHERWISE DAMAGED. CONTACT HENDRICKSON TO ORDER REPLACEMENT LABELS.

#### FIGURE 3-1





### **PARTS CLEANING**

SOLVENT CLEANERS CAN BE FLAMMABLE, POISONOUS AND CAUSE BURNS. TO HELP AVOID SERIOUS PERSONAL INJURY, CAREFULLY FOLLOW THE MANUFACTURER'S PRODUCT INSTRUCTIONS AND GUIDELINES AND THE FOLLOWING PROCEDURE:

- WEAR PROPER EYE PROTECTION
- 2. WEAR CLOTHING THAT PROTECTS YOUR SKIN
- 3. WORK IN A WELL VENTILATED AREA
- 4. DO NOT USE GASOLINE, OR SOLVENTS THAT CONTAIN GASOLINE. GASOLINE CAN EXPLODE
- 5. ACIDIC SOLUTIONS CANNOT BE USED ON ALUMINUM COMPONENTS
- 6. HOT SOLUTION TANKS OR ALKALINE SOLUTIONS MUST BE USED CORRECTLY. FOLLOW THE MANUFACTURER'S RECOMMENDED INSTRUCTIONS AND GUIDELINES CAREFULLY TO HELP PREVENT PERSONAL ACCIDENT OR INJURY

DO NOT USE HOT SOLUTION TANKS OR WATER AND ALKALINE SOLUTIONS TO CLEAN GROUND OR POLISHED PARTS. DOING SO WILL CAUSE DAMAGE TO THE PARTS AND VOID ANY APPLICABLE WARRANTY.




#### **ELECTRIC VEHICLE SAFETY**

PRIOR TO PERFORMING ANY WORK ON THE VEHICLE, READ ALL WORK INSTRUCTIONS AND SAFETY INFORMATION PROVIDED BY THE VEHICLE MANUFACTURER AND MAKE SURE THAT THE STARTER SWITCH IS IN THE "OFF" POSITION, SET THE PARKING BRAKE, AND CHOCK THE TIRES.

TOOLS USED WHEN WORKING NEAR BATTERIES OR ELECTRICAL CONNECTIONS MUST BE CERTIFIED TO A RATING OF 1000 VDC TO HELP PREVENT INJURIES FROM ELECTRIC SHOCK. SHORT CIRCUITS BETWEEN COMPONENTS OR WIRES MUST BE AVOIDED.



# SECTION 4 Parts Lists





# SOFTEK® Front Suspension for Workhorse W56 Electric Step Vans

KFY N	O. PART NO.	DESCRIPTION	VEHICLE QTY.
2	82988-000	Leaf Spring Assembly	2
2	64488-002	Front Hanger	
	34013-436	Front Spring Eye Fastener Service Kit, On Includes Key Nos. 3-5	ne Side,
3		*3/4"-10 UNC x 7" Hex Bolt	2
3 4		*¾" Flat Washer	4
5 6 7		*3/4"-10 UNC Locknut	2 4 2 2 4
6	66510-001	Rear Shackle Bracket Assembly	2
7	64314-001	Rear Shackle Plate	4
	34013-476	Rear Shackle Bracket Fastener Service I	(it,
		One Side, Includes Key Nos. 8-10	
8		*34"-16 UNF x 61/2" Hex Bolt	4
9		*¾" Flat Washer	8
10		*3/4"-16 UNF Nylocknut	4
11	94144-004	Shock Absorber	2 2
12	94145-100	Upper Shock Absorber Bracket	2
	50754-089	Single Shock Absorber Fastener Service	Kit,
13		Includes Key Nos. 13-16	
13		*5%"-11 UNC x 4" Upper Shock Bolt  *5%"-11 UNC x 7" Lower Shock Bolt	
15		*%" Flat Washer	2 2 6
16		*5%"-11 UNC Hex Locknut	0
17	04222.002		4 2
17	94333-003 94134-000	Shock Absorber Spacer  Top Pad / Axle Stop Assembly, Includes Ke Nos. 18-19	
18		*Top Pad	2
19		*Rubber Axle Stop	2
17	91430-085	U-bolt Service Kit, One Side, Includes Ke	
	71400 000	and Kit No. 48718-504	
20		*%"-18 UNF x 6½" Square U-bolt	4
	48718-504	U-bolt Fastener Service Kit, One Side,	
01		Includes Key Nos. 21-22	
21		*5%" Flat Washer	8
22	04200 003	*%"-18 UNF Hex High Nut	8
	94399-001	STEERTEK NXT Axle Assembly Includes Key Nos. 23-41	I


KEY NO	). PART NO.	VEH DESCRIPTION	ICLE QTY.
23	94166-003M	Axle & Kingpin Assembly	1
		Lower Steering Knuckle Assembly,	
		Includes Key Nos. 30-32, 35-36	
24	91221-501	Left Hand	1
25	91221-502	Right Hand	1
		Upper Steering Knuckle Assembly,	
		Includes Key Nos. 28-29, 31-32	
26	93605-006	Left Hand	1
27	94174-001	Right Hand	1
	34013-448	Kingpin Bushing and Bearing Service Kit,	
		One Side, Includes Key Nos. 28-34 & Loctite	
28	33117-000	Grease Zerk	2
29	91231-001	Grease Cap Assembly, Upper	2
30	91233-001	Grease Cap Assembly, Lower	2 2
31	91204-0011	Kingpin Bushing	4
	34013-449	Roller Thrust Bearing Service Kit, One Side,	
		Includes Key Nos. 32-34 & Loctite	
32	91234-001	Kingpin Seal	4
33	91202-001	Roller Thrust Bearing	2
34	60236-004	1/2"-13 UNC Socket Head Cap Screw	4
Not Shown	60937-000	Loctite® (Red) Compound Tube	1
	60961-069	Stop Bolt Service Kit, One Side,	
		Includes Key Nos. 35-36	
35		*½"-13 UNC Square Head Bolt	2
36		*½"-13 UNC Hex Jam Nut	2
37	91226-005	Tie Rod Assembly, Drop, Includes Key Nos. 38-4	10 1
		Tie Rod End Service Kits	
	34013-499	Axle Set, Includes Left Hand and Right Hand	l Kits
	34013-500	Left Hand, Includes Key Nos. 38, 40-41	
	34013-501	Right Hand, Includes Key Nos. 39-41	
		Tie Rod End, Includes Key No. 40	
38	91226-101	Left Hand	1
39	91226-102	Right Hand	1
40		*3/4" Castle Nut	2
41	17800-004	Tie Rod Nut Cotter Pin	2

NOTES: Quantities specified are for the vehicle. Quantities of service kit components may vary from amount shown in the list.

<sup>\*</sup> Item included in assembly only, part not sold separately.



# Wheel End Assembly with Hydraulic Disc Brakes



		VEHI	CLE
KEY NO	). PART NO.	DESCRIPTION	QTY.
1		**Bosch Torque Plate Assembly	
		Left Hand, Part No. 0 204 002 771	1
		Right Hand, Part No. 0 204 002 772	1
2	24531-004	½"-13 UNC x 2½" Brake Mounting Hex Bolts	8
		(Primary)	
3	24531-007	½"-13 UNC x 1½" Brake Mounting Hex Bolts	8
		(Secondary)	
4	22962-011	½" Hardened Flat Washer	16
5		**Bosch ABS Sensor Bracket	2
		Part No. 0 204 793 126	
6	93398-001	5/16"-18 UNC x ½" Lobe Bolt	10
6 7 8 9	93274-010	M10 x 1.5 Lobe Screw	8
8		**Bosch Brake Pads, Part No. 0 204 816 587	4
9		**Bosch Hydraulic Disc Brake Caliper Assembly	, 2
		Part No. 0 204 719 661	
10		**Bosch M12 x 1.25 x 40 Hex Bolt	4
		Part No. 0 204 062 176	
11		**7/16" Bleeder Screw, Part No. 0 204 AJ2122	2
12		**Bosch Dust Shield, Part No. 0 204 793 130	2 2 2
13		**Webb Disc Brake Hub & Rotor Assembly,	2
		Includes Key Nos. 14-20, Part No. 25505XX5	
14		**Disc Brake Rotor Part No. 54770P-98	2

		VEH	HICLE
KEY NO	O. PART NO.	DESCRIPTION	QTY.
15		**Hub Assembly Includes Key Nos. 16-17 Part No. 25501-0	2
16		*Inner Bearing Cup	2 2 16
17		*Outer Bearing Cup	2
18		**M22 Wheel Stud 2.4" Standout Part No. 101193	16
19		**3/4" Cap Screw (Not Shown) Part No. 87511	12
20		**3/4" Flat Washer (Not Shown) Part No. 257	12
21		**The Timken Company Inner Bearing Cone Part No. JM207049A	2
22		**The Timken Company Outer Bearing Cone Part No. 25877-01	2
23		**DRiV Incorporated Wheel Seal Part No. 370150A	2
24		**SKF Hubcap Assembly, Part No. 1608 Includes Key Nos. 25-26	2
25		**Hubcap Gasket Part No. 453868	2
26 27		**Hubcap Bolts Part No. 454304	8
27		Spindle Lock Washer	4
28	91242-000	11/8"-12 Spindle Nut	2
29	93288-000	Spindle Nut Lock	2 8 4 2 2 2
30	17800-004	Spindle Nut Cotter Pin	
31		***M22 x 1.5 Lug Nut	16

NOTES: Quantities specified are for the vehicle. Quantities of service kit components may vary from amount shown in the list.

- \* Item included in assembly only, part not sold separately.
- \*\* These components are installed by Hendrickson for new production assembly but not supplied for aftermarket service purposes.

  Description and part number listed for reference only. For more information and assistance with service, maintenance and rebuild instructions on these components see below component manufacturers:
  - Bosch technical and parts support 888.715.3616 or online www.boschautoparts.com
  - DRiV Incorporated parts support 800.325.8886 or online www.drivparts.com
  - SKF parts support 800.533.6563, e-mail: vsm.aftermarket.custsrv@skf.com, website: vehicleaftermarket.skf.com
  - The Timken Company technical and parts support 866.984.6536 or online www.timken.com
  - Webb Wheel Products technical and part support 800.633.3256 or online www.webbwheel.com
- \*\*\* Not supplied by Hendrickson, used for reference only. Contact the vehicle manufacturer for more information.



# Special Tools

# KINGPIN BUSHING TOOL - ADJUSTABLE STRAIGHT FLUTE REAMER


The dimension of cutting diameter must facilitate a range of 1.351" – 1.361"




The dimension of cutting diameter must facilitate a range of 1.781 - 2.093

### KINGPIN BUSHING AND SEAL SHOP MADE TOOLS

**SHOP MADE TOOLS:** These shop made tools are designed to install and remove kingpin bushings. Bushing tools are made from cold rolled steel or equivalent. Drawings are for reference only. Hendrickson does not supply these tools.



**NOTE:** \*The bushing driver is necessary to sink the kingpin bushing flush into the steering knuckle bore.



**NOTE:** \*The Kingpin Handle is used for both bushing installer / remover and seal installer tools



# SECTION 6 Towing Procedure

# TOWING/TRANSPORT OF ELECTRIC VEHICLES

**DO NOT** tow or otherwise transport an electric vehicle equipped with a SOFTEK front suspension system using any method that is not specified by the vehicle manufacturer. Please read, understand, and comply with all towing/transport instructions and safety precautions that may be provided by the electric vehicle manufacturer as well as all applicable government rules and regulations.

Hendrickson will not be responsible for any damage to the SOFTEK suspension system or other vehicle components resulting from any towing/transport method or fixture not authorized by the vehicle manufacturer.



# SECTION 7 Preventive Maintenance



### **ELECTRIC VEHICLE SAFETY**

PRIOR TO PERFORMING ANY WORK ON THE VEHICLE, READ ALL WORK INSTRUCTIONS AND SAFETY INFORMATION PROVIDED BY THE VEHICLE MANUFACTURER AND MAKE SURE THAT THE STARTER SWITCH IS IN THE "OFF" POSITION, SET THE PARKING BRAKE, AND CHOCK THE TIRES.

TOOLS USED WHEN WORKING NEAR BATTERIES OR ELECTRICAL CONNECTIONS MUST BE CERTIFIED TO A RATING OF 1000 VDC TO HELP PREVENT INJURIES FROM ELECTRIC SHOCK. SHORT CIRCUITS BETWEEN COMPONENTS OR WIRES MUST BE AVOIDED.

### HENDRICKSON RECOMMENDED INSPECTION INTERVALS

Following appropriate inspection procedures is important to help ensure the proper maintenance and operation of the SOFTEK front suspension system equipped with STEERTEK NXT axle and components function to their highest efficiency.

Hendrickson recommends to visually inspect for proper assembly and function, overall condition and any signs of damage. Check for all of the following as per the inspection intervals shown and replace components as necessary:

 Signs of unusual movement, loose or missing components, abrasive or adverse contact with other components, damaged or cracked parts and improper suspension function or alignment

	PRE-DELIVERY	FIRST IN-SERVICE	PREVENTIVE N	MAINTENANCE
	within the first 100 miles (160 km)	1,000 miles (1,600 km), 100 hours or whichever comes first	15,000 miles (24,000 km), every 3 months or whichever comes first	25,000 miles (40,000 km), every 6 months or whichever comes first
Axle Assembly and Tie Rod			•	
Clamp Group		•		
Fasteners		•		•
Front Hanger Plate, Rear Shackle Bracket and Shackle Plate	•	•	•	
Front and Rear Spring Eye Connection				
Leaf Spring Assembly			•	
Shock Absorber				
Steering Operation				
Tire Wear				
Top Pad and Bump Stop				
Wear and Damage			•	

See the vehicle manufacturer's applicable publications for other preventive maintenance requirements.

### COMPONENT INSPECTION

- Axle assembly and Tie rods Visually inspect for any cracks or dents on the axle, refer to Tie Rod Ends in this section. Replace as necessary.
- Clamp group Check torque on clamp group mounting hardware. Refer to the Clamp Group Re-torque Intervals in this section.

17730-356 13 Preventive Maintenance



■ Fasteners — Visually inspect for any loose or damaged fasteners on the entire suspension. Make sure all fasteners are tightened to the specified torque. Refer to the Torque Specifications section of this publication. Use a calibrated torque wrench to check torque in a tightening direction. As soon as the fastener starts to move, record the torque. Correct the torque if necessary. Replace any worn or damaged fasteners.

### NOTE

Torque values shown in this publication apply only if Hendrickson supplied fasteners are used. If non-Hendrickson fasteners are used, follow the torque specifications listed in the vehicle manufacturer's service manual.

- Front hanger plates, rear shackle brackets and shackle plates Visually inspect for any cracks or loose mounting hardware. Replace if necessary, see the Component Replacement section of this publication for replacement procedure.
- Front and rear spring eye connection Visually inspect for any cracks or damage to spring eye bushing. Visually inspect for any loose or damaged fasteners. Ensure the spring eye fasteners are tightened to the specified torque.
- Leaf spring assembly Visually inspect for any cracks. Replace if cracked or broken, see the Component Replacement section of this publication for replacement procedure.
- Shock absorbers Visually inspect for any signs of dents or leakage, misting is not considered a leak. See Shock Absorbers in this section.
- Steering operation All steering components must move freely through the full range of motion from axle stop to axle stop. Check for looseness at all pivot points. Inspect and lubricate all pivot points. Refer to the Troubleshooting Guide section of this publication.
- **Tire wear** Visually inspect the tires for any wear patterns that may indicate suspension damage or misalignment, see Visual Tire Inspection in this section.
- **Top pad and bump stop** Visually inspect for any cracks and/or missing rubber bump stops. Replace if necessary, see the Component Replacement section of this publication for replacement procedure.
- Wear and damage Visually inspect all parts of suspension for wear and damage. Replace all worn or damaged parts.

### **LUBRICATION INTERVALS**

For vehicles equipped with the STEERTEK NXT axle, regular lubrication intervals should be followed to help prevent premature wear to the kingpin bushings and tie rod ends, see Lubrication Specifications in Table 7-1.

**NOTE** 

The recommended service lubrication interval is a guideline, the vehicle may require increased lubrication intervals depending on severity of operation.

TABLE 7-1		SOFTEK with STEERTEK NXT Axle Greasing and Lubrication Specifications					
	Application		Component	Greasing Interval	Grease	Outside Temperature	
	Low Mileage Accumulation No off-road		Kingpin Bushings		Multinumana	Refer to the lubricant	
≥	operation	C	Tie Rod Ends	25,000 miles (40,233 km) or 3 months, whichever comes	Multipurpose Grease NLGI Grade 2	manufacturer's specifications for the temperature service limits applicable to	
Ë	95% Highw	•					
MEDIUM-DUTY		adway operation ery, Inner City Coach, Heavy-haul,					
				first		your area	
Σ		motor home, transit coach 5,000 miles per year (40,233 per year)	Drag Link	See Vehicle Manufacturer			

**NOTE:** Lubrication greases acceptable for use on the STEERTEK NXT axle will carry a designation of NLGI #2 EP and rated GC-LB or equivalent.

FIGURE 7-2

Roller bearing

purge vent



### KINGPIN LUBRICATION

STEERTEK NXT upper kingpin grease zerks are located on the inboard side of the steering knuckle and upper kingpin connection, see Figure 7-1.

FIGURE 7-1



- 1. Place vehicle on the ground.
- 2. Chock the wheels.
- 3. Prior to greasing the kingpins on the vehicle, the suspension must be in a loaded condition.
- 4. Clean off all the grease zerks and grease gun tip with a clean shop towel prior to lubrication.
- 5. Lubricate the kingpins through the grease zerks on the top and bottom of the steering knuckle, see Lubrication Specification Table 7-1.
- 6. Force the required lubricant into the upper and lower kingpin grease zerks, until new lubricant flows out from the upper kingpin connection and steering knuckle and the thrust bearing purge location, see Figure 7-2.

**NOTE** 

Greasing at the lower fitting should purge grease from the thrust bearing shell. The STEERTEK NXT Axle for Workhorse vehicles is equipped with a steel roller thrust bearing on both left and right sides.

7. Remove the wheel chocks.

# **TIE ROD ENDS**

### **INSPECTION**

Prior to inspection the entire system must be unloaded (i.e., the front end of the vehicle must be raised and supported with safety stands).



DO NOT GREASE THE TIE ROD ASSEMBLY BEFORE PERFORMING THE INSPECTION. DOING SO CAN INHIBIT EFFORTS TO DETERMINE ACTUAL WEAR.



REPLACE THE ENTIRE TIE ROD END IF THE BOOT IS TORN OR MISSING, FAILURE TO DO SO CAN CAUSE PREMATURE WEAR OF THE TIE ROD END.

- 1. Chock the rear wheels of the vehicle.
- 2. Use the bottom of the axle beam or the frame rails to raise the front end of the vehicle off the ground and support with safety stands.
- 3. With the engine turned off, turn the wheels from full left to full right and then return to the straight-ahead position.
- 4. Check that the boots are in place and completely installed over the tie rod ends.
- 5. Check for cracking or tears in the boots. Also check the boot seals for damage. Replace the entire tie rod end if the boot is damaged.



THE COTTER PIN MUST BE INSTALLED CORRECTLY THROUGH THE TIE ROD END WITH THE CASTLE NUT TIGHTENED TO THE PROPER TORQUE SPECIFICATION IN ORDER TO SECURELY ATTACH THE TIE ROD. LOSS OF THE COTTER PIN CAN CAUSE THE TIE ROD END NUT TO BECOME LOOSE AND POSSIBLY RESULT IN TOTAL LOSS OF VEHICLE CONTROL.





6. Check that the tie rod end nut is installed and secured with a cotter pin. If the cotter pin is missing, check the nut torque specification and then install a new cotter pin. Always tighten the castle nut to specified torque when setting the cotter pin. **DO NOT** back off the nut to insert cotter pin.



IT IS CRITICAL TO CHECK THE TIE ROD CLAMP BOLT HEAD LOCATION TO VERIFY THE CLAMP FASTENERS HAVE SUFFICIENT CLEARANCE AWAY FROM THE LOWER SHOCK MOUNT AT FULL WHEEL CUT. THE FASTENERS MUST NOT CONTACT THE LOWER SHOCK MOUNT. FAILURE TO DO SO CAN CAUSE ONE OR MORE COMPONENTS TO FAIL CAUSING LOSS OF VEHICLE CONTROL AND POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE.


7. Verify the tie rod clamp bolt head does not contact the lower shock mount at full wheel cut, see Figure 7-3.



THE THREADED PORTION OF THE TIE ROD END MUST EXTEND PAST THE SLOTS INTO THE TIE ROD CROSS TUBE, SEE FIGURE 7-3. FAILURE TO DO SO CAN CAUSE COMPONENT DAMAGE, LOSS OF VEHICLE CONTROL AND POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE.

- 8. Check that the tie rod end is threaded correctly into the cross tube and is engaged deeper than the end of the cross tube slot. The tie rod end must be visible the entire length of the cross tube slot, see Figure 7-3.
- 9. Check that grease zerks are installed. Replace a damaged grease zerk with a new one.

### FIGURE 7-3



### 1/2" Tie Rod Clamp Bolt

It is critical to check the  $\frac{1}{2}$ " tie rod clamp bolt head location to verify the clamp fasteners have sufficient clearance away from the lower shock mount at full wheel cut. The fasteners must not contact the lower shock mount.

#### Tie Rod Cross Tube Slots

It is critical to have the threaded portion of the tie rod end extend past the slots in the tie rod cross tube.

½"Tie Rod Clamp Locknut Tightening Torque 68 ± 7 ft. lbs. (92 ± 9 Nm)

# **A** CAUTION

DO NOT USE THE FOLLOWING ITEMS OR METHODS TO CHECK FOR MOVEMENT OF THE TIE ROD ASSEMBLY, WHICH CAN CAUSE DAMAGE TO COMPONENTS:

- A CROW BAR, PICKLE FORK OR 2 x 4
- ANYTHING OTHER THAN HANDS USED TO GRASP AND ROTATE THE CROSS TUBE ASSEMBLY (CAN RESULT IN DAMAGE TO THE CROSS TUBE)
- EXCESSIVE PRESSURE OR FORCE APPLIED TO THE TIE ROD ENDS OR THE JOINTS OF THE ASSEMBLY
- 10. By hand or using a pipe wrench, with jaw protectors to avoid gouging the cross tube, rotate the cross tube toward the front of the vehicle and then toward the rear. After rotating, center the cross tube. If the cross tube will not rotate in either direction, replace both tie rod ends, see Figure 7-4.
- 11. Position yourself directly below the tie rod end. Using both hands, grab the assembly end as close to the tie rod end as possible (no more than 6" or 152.4 mm). Apply hand pressure with reasonable human effort vertically up and down in a push-pull motion several times, using approximately \$\mathbb{\Ta}\$ 75 \pm 25 foot pounds of force. Check for any movement or looseness at both tie rod end locations, see Figure 7-5.
- 12. If there is any movement in the tie rod assembly, install a magnetic based dial indicator on the lower steering knuckle, see Figure 7-6.
- 13. Set the dial indicator to zero.
- 14. Apply hand pressure with reasonable human effort vertically up and down in a push-pull motion several times (using approximately  $75 \pm 25$  foot pounds of force). Observe the reading on the dial indicator.




FIGURE 7-4









15. If the reading is more than 0.060", replace both tie rod ends at the next service interval.

16. If a tie rod end exhibits ≥ 0.125" of movement by hand, the vehicle should be removed immediately from use and the tie rod end be replaced.

NOTE

According to the Commercial Vehicle Safety Alliance (CVSA), the "out of service" criteria for front steer axle tie rod assemblies on any commercial vehicle is: Any motion other than rotational between any linkage member and its attachment point of more than 1/8" (3 mm) measured with hand pressure only. (393.209(d)), (published in the North American Standard Out-of-Service Criteria Handbook, 2024.)






FIGURE 7-7

- 17. Remove the vehicle frame safety stands and lower the vehicle.
- 18. Remove the rear wheel chocks.

### **LUBRICATION PROCEDURE**

- 1. Turn the vehicle wheels straight ahead.
- 2. Chock the wheels.
- 3. Wipe the grease zerk and grease gun tip with clean shop towels.
- 4. Wipe the seal / boot clean with shop towels.
- 5. Attach a grease gun to the grease zerk. Either a hand or pneumatic grease gun is acceptable. If air operated grease gun is used, system air pressure should not exceed 150 psi (1035 kPa).





EXCEEDING THE MAXIMUM AIR PRESSURE TO THE GREASE ZERK CAN CAUSE DAMAGE TO THE DUST BOOT AND COMPONENT FAILURE.

- 6. Dirt, water, and discolored old grease should flow from the relief vents or purge holes near the boot crimp or bellows area, see Figure 7-7.
- 7. Continue to purge grease until fresh grease flows from the purge area.
- 8. The tie rod ends are designed for lube service. If a tie rod end will not accept grease proceed as follows:
  - a. Remove the grease zerk.
  - b. Inspect the threaded grease zerk hole in the tie rod end and remove any obstructions.



- c. Install a new grease zerk.
- d. Continue the lubrication procedure.

### NOTE

If the tie rod end still does not accept grease following this procedure, replace the tie rod end (see Tie Rod End and Cross Tube in the Component Replacement section of this publication).

9. Remove the wheel chocks.

# **CLAMP GROUP**

### **RE-TORQUE INTERVALS**




LOOSE OR OVER TORQUED FASTENERS CAN CAUSE COMPONENT DAMAGE, LOSS OF VEHICLE CONTROL, PROPERTY DAMAGE, OR SEVERE PERSONAL INJURY. MAINTAIN CORRECT TORQUE VALUES AT ALL TIMES. CHECK TORQUE VALUES ON A REGULAR BASIS AS SPECIFIED.


1. Clamp group locknuts must be torqued to specification at preparation for delivery and re-torqued at 1,000 miles thereafter, follow the 3 month / 15,000 mile, whichever comes first visual inspection and annual re-torque intervals.



ENSURE THE CLAMP GROUP IS ALIGNED PROPERLY PRIOR TO TIGHTENING HARDWARE. FAILURE TO DO SO CAN CAUSE LOSS OF VEHICLE CONTROL, PROPERTY DAMAGE OR PERSONAL INJURY.

- 2. Ensure that the clamp group is properly aligned and the U-bolts are seated in the top pad, and the top pad is centered on the axle spring seat, see Figure 7-8.
- 3. Visually inspect for the signs of component or bolt movement. If signs of movement are present:
  - Disassemble the clamp group fasteners, check for component wear or damage and replace as necessary, then install new clamp group fasteners.
  - b. Tighten the clamp group locknuts evenly in 50 foot pounds increments to  $3180 \pm 15$  foot pound torque in the proper pattern to achieve uniform bolt tension, see Figure 7-9.





# KINGPIN BUSHING

NOTE

If one (1) bushing is worn or damaged, it is mandatory to replace both the top and bottom bushings on that knuckle assembly.

## INSPECT THE STEERING KNUCKLE LATERAL MOVEMENT

- 1. Chock the wheels to help prevent the vehicle from moving. Set the parking brake.
- 2. Use a jack to raise the vehicle until the wheels are off the ground. Support the vehicle with safety stands.
- 3. **CHECK THE UPPER KINGPIN BUSHING**. Install the base of a dial indicator onto the axle beam and place the tip against the side of the steering knuckle, see Figure 7-10.
- 4. Set the dial indicator to "0" zero.



- 5. Move the **TOP** of the tire in and out by applying reasonable constant pressure and then release, see Figure 7-12.
- 6. Check the reading on the dial indicator. If the dial indicator moves:
  - more than 0.015", the upper bushing is worn or damaged. Replace both kingpin bushings. Refer to the Kingpin Bushing replacement procedure in the Component Replacement section of this publication.
  - less than 0.015", proceed to Step 7.
- 7. **CHECKTHE LOWER KINGPIN BUSHING**. Install a dial indicator so that the base is on the axle and the indicator tip is against the inside of the bottom of the knuckle, see Figure 7-11.

FIGURE 7-10
Check the UPPER Kingpin Bushing



FIGURE 7-11
Check the LOWER Kingpin Bushing



FIGURE 7-12 Move the TOP and BOTTOM of the tire in and out



- 8. Set the dial indicator to "0" zero.
- 9. Move the **BOTTOM** of the tire in and out. If the dial indicator moves:
  - more than 0.015", the lower bushing is worn or damaged. Replace both kingpin bushings. Refer to the Kingpin Bushing replacement procedure in the Component Replacement section of this publication.
  - less than 0.015", proceed to Step 10.
- 10. Lower the vehicle and remove the safety stands.
- 11. Remove the wheel chocks.


### STEERING KNUCKLE

# CHECKING VERTICAL END PLAY (UP AND DOWN MOVEMENT)

The operating specification for vertical end play on the steering knuckle is 0.008" to 0.030".

- 1. Chock the rear tires to help prevent the vehicle from moving.
- 2. Set the parking brakes.
- 3. Use a jack to raise the vehicle until both tires are 1" off the ground.
- 4. Place a dial indicator on each side of the axle as follows:
  - a. Index the wheels slightly (left or right).
  - b. Place the magnetic dial indicator base on the axle, see Figure 7-13.

#### FIGURE 7-13





- c. Place the tip of the dial indicator on the top of the upper steering knuckle (not on the grease cap).
- 5. Set the dial indicator to "O" (zero).
- 6. Lower the jack.
- 7. If vertical end play is greater than 0.030", or below 0.008" an adjustment of the upper knuckle is necessary.
- 8. Upper steering knuckle adjustment:
  - Remove brake assembly per vehicle manufacturer's instructions.
  - If the vertical end play is greater than 0.030", loosen the socket head cap screws and push **down** on the knuckle assembly until the proper vertical end play is achieved.
  - If the vertical end play is **less than 0.008**", loosen the socket head cap screws and **pull up** on the knuckle assembly until the proper vertical end play is achieved.
- 9. Retighten the socket head cap screws to  $\P$  110  $\pm$  10 foot pounds torque.
- 10. Install brake assembly as per vehicle manufacturer's instructions.
- 11. Remove the safety stands and lower the vehicle.
- 12. Remove wheel chocks.

### SHOCK ABSORBERS

NOTE

It is not necessary to replace shock absorbers in pairs if only one (1) shock absorber requires replacement.

Hendrickson uses a long service life, premium shock absorber on all SOFTEK suspensions. If shock absorber replacement is necessary, Hendrickson recommends that the shock absorbers be replaced with identical Hendrickson Genuine part for servicing. Failure to do so will affect the suspension performance, durability, and will void any applicable warranty. See vehicle manufacturer's applicable publications for other shock absorber inspection requirements.

Inspection of the shock absorber can be performed by doing a heat test, and a visual inspection. Replace as necessary, refer to the Component Replacement section of this publication.

### **HEAT TEST AND PHYSICAL INSPECTION**

1. **Heat Test:** Drive the vehicle at moderate speeds on a rough road for minimum of fifteen minutes.

DO NOT GRAB THE SHOCK ABSORBER AS IT COULD POSSIBLY BE

- HOT AND CAUSE PERSONAL INJURY.
  - a. Perform heat test by carefully touching or placing a hand near the shock absorber body below the dust cover. Touch the frame to get an ambient reference, see Figure 7-14. A shock absorber that is warm to the touch is acceptable, a cold shock absorber should be replaced.
- 2. Physical Inspection: To inspect for an internal failure, remove and shake the suspected shock absorber. Listen for the sound of metal parts rattling inside. Rattling of metal parts can indicate that the shock absorber has an internal failure and the shock absorber should be replaced.







### VISUAL INSPECTION

Look for these potential problems when doing a visual inspection, see Figure 7-15. Inspect the shock absorbers fully extended. Replace as necessary.

### FIGURE 7-15



Damaged upper or lower mount

### SHOCK ABSORBER VISUAL INSPECTION - UNACCEPTABLE CONDITIONS



Damaged upper or lower bushing



Damaged dust cover and / or shock body



Bent or dented shock absorber



Improper installation Example: washer (if equipped installed backwards


### LEAKING VS. MISTING SHOCK ABSORBER VISUAL INSPECTION

The inspection must not be conducted after driving in wet weather or a vehicle wash. The shock absorber needs to be free from water.

Many shock absorbers are often misdiagnosed as failures. Misting is the process whereby very small amounts of shock absorber fluid evaporate at a high operating temperature through the upper seal of the shock absorber. When the "mist" reaches the cooler outside air, it condenses and forms a film on the outside of the shock absorber body. Misting is perfectly normal and necessary function of the shock absorber. The fluid which evaporates through the seal area helps to lubricate and prolong the life of the seal.

SOFTEK suspension systems are equipped with a premium seal on the shock absorber, however this seal will allow for misting to appear on the shock absorber body (misting is not a leak and is considered acceptable).

FIGURE 7-16



### **NOTE**

Inspect the shock absorber fully extended. A shock absorber that is truly leaking will show signs of fluid leaking in streams from the upper seal. These streams can easily be seen, see Figure 7-16, underneath the main body (dust cover) of the shock absorber. Replace as necessary.




### **VISUAL TIRE INSPECTION**

The following tire Inspection guidelines are based upon Technology & Maintenance Council (TMC) recommended practices. Any issues regarding irregular tire wear where Hendrickson is asked for assistance, will require tire and alignment maintenance records, reference RP 642 in TMC Recommended Practices Manual.

Tire wear is normally the best indicator of vehicle alignment condition. If tires are wearing too rapidly or irregularly, alignment corrections may be needed. The tire wear patterns described below can help isolate specific alignment problems.

The most common conditions of concern for steer tires are: cupping, diagonal wear, feather wear, one-sided wear, overall fast wear (Miles per 32nd), and rapid shoulder wear (one shoulder only).

FIGURE 7-17



**Cupping** — Localized, dished out areas of fast wear creating a scalloped appearance around the tire. Cupping, which appears around the tire on the shoulder ribs, may also progress to adjoining ribs.

Cupping is usually a result of moderate-to-severe imbalance, improper rim/wheel mounting, excessive wheel end play or other assembly non-uniformity. It can also be due to lack of shock absorber control on some suspension types as well as loose kingpins.

To solve cupping problems:

**Tires** – Correct mismount or balance problem. If ride complaints arise, steer tires may be rotated to drive or trailer axle.

**Vehicle** – Diagnose component imbalance condition, i.e., wheel, rim, hub, brake, drum. Correct as necessary.

**Diagonal Wear** — Is localized flat spots worn diagonally across the tread at approximately 25-35° angles, often repeating around the tread circumference.

Diagonal wear is usually caused by bad wheel bearings, toe out, mismounting of tire and wheel assembly to axle, and mismatched duals for size and/or inflation pressures. It may start as brake skid. Diagonal wear is aggravated by high speed empty or light load hauls.

To correct diagonal wear, reverse direction of rotation of the tire. If wear is excessive, true or retread tire. If the source of trouble is the vehicle, diagnose cause and correct as needed.

FIGURE 7-19



**Feather wear** — Tread ribs or blocks worn so that one side is higher than the other resulting in step–offs across the tread face. Generally, all ribs or blocks exhibit this wear.

**To spot this problem do the following:** With one hand flat on the tread of the  $| \times \times \times |$  tire and a firm down pressure, slide your hand across the tread of the tire. In one direction, the tire will feel smooth and in the opposite direction there will be a sharp edge to the tread.

If feather wear on both steer tires is in the same direction, drive axle or other chassis misalignment is indicated. If one steer tire shows feather wear and the other steer tire has normal wear, a combination of toe and drive axle or chassis misalignment is indicated.

**One-sided wear** — Is excessive wear on one side of tire extending from the shoulder towards the center of the tread.

One-sided wear is usually caused by improper alignment, worn kingpins, loose wheel bearings, excessive negative camber, excessive axle loads, nonparallel axles, or non-uniform tire and wheel assembly caused by improper bead seating or a bent wheel.


To correct one-sided wear:

**Tires** – Depending on severity, rotate tires to another axle position or, if worn to minimum tread depths, submit for possible retreading.

**Vehicle** – Diagnose mechanical problem and correct.








# SOFTEK® Front Suspension for Workhorse W56 Electric Step Vans

### **FIGURE 7-21**

OVERALL FAST WEAR (Miles per 32nd)




**Overall Fast Wear** — Fast wear can be described as exhibiting a good, but accelerated wear pattern. It is typically caused by operating conditions, such as mountainous terrain, frequency and severity of turning, abrasive road surfaces in combination with vehicle configurations and their attributes. To correct this problem, consult with vehicle and tire manufacturers when specifying equipment or replacing tires.

This wear condition is usually caused by excessive toe or excessive camber. These conditions can be created by a misaligned or bent axle and can also be caused by loose or worn wheel bearings. To correct this type of rapid shoulder wear:

Tires – Change direction of rotation of tire. If shoulder wear is severe, remove and retread.

**Vehicle** – Diagnose misalignment and/or mechanical condition and correct.

# FIGURE 7-22 RAPID SHOULDER WEAR (One Shoulder Only)



# WHEEL END AND HYDRAULIC DISC BRAKE ASSEMBLIES AND COMPONENTS

### NOTE


Wheel end hubs, seals, bearing cones, hub caps, as well as hydraulic disc brake assemblies and components are installed by Hendrickson for new production assembly but these components are not supplied by Hendrickson for aftermarket service purposes. For more information and assistance with service, maintenance and rebuild instructions on these items see the below listed component manufacturers. Refer to the Parts Lists section of this publication for additional information on such assemblies and components.

- Bosch technical and parts support 888.715.3616 or online www.boschautoparts.com
- DRiV Incorporated parts support 800.325.8886 or online www.drivparts.com
- SKF parts support 800.533.6563, e-mail: vsm.aftermarket.custsrv@skf.com, website: vehicleaftermarket.skf.com
- The Timken Company technical and parts support 866.984.6536 or online www.timken.com
- Webb Wheel Products technical and part support 800.633.3256 or online www.webbwheel.com



# **SECTION 8** Alignment & Adjustments

### **ALIGNMENT DEFINITIONS**



results in wheel scrub in turns which generally appears as toe wear on the tire, usually more wear on one side of the vehicle than the other due to the operational route of the vehicle. **Bump Steer (Feedback)** — The feedback felt through the steering linkage to the steering wheel when a steer axle tire hits a bump in the road. This occurs because the axle-end of the drag link and the axle attachment point of the spring do not travel in parallel circular arcs as the suspension moves up and down. This condition can also be caused by trapped air in the power steering system.

> **Camber** — The angle formed by the inward or outward tilt of the wheel reference to a vertical line. Camber is positive when the wheel is tilted outward at the top and is negative when the wheel is tilted inward at the top.

Lower Steering Knuckle (Ackermann Arm) Geometry — The geometry of the four bar linkage consisting of the front axle beam pivot points, tie rod arms, and cross tube and attempts to provide free rolling of

front tires in a turn. Ackermann geometry is dependent upon the steering axle track-width and wheelbase of the vehicle. Improper geometry

Excessive positive camber may cause smooth wear on the outer half of the tire tread. Excessive negative camber may cause wear on the inner half of the tread. Static-unloaded camber angles are built into the axle to put the loaded tire perpendicular to the road.





FIGURE 8-3




**Caster** — The forward or rearward tilt of the steering axle kingpin in reference to a vertical line. The angle is measured in degrees. Caster is positive when the top of the steering axis is titled rearward and is negative when the tilt is forward. Proper caster is important for directional stability and returnability. Too much positive caster can cause shimmy, excessive steering effort and is normally a vehicle performance and handling consideration. Uneven positive caster may create a steering pull toward the side with the lower caster. This attribute may be used to compensate for crowned roads.

**Kingpin Inclination** — The inward tilt of the kingpin from the vertical. This front suspension parameter has a pronounced effect on steering effort and returnability. As the front wheels are turned around an inclined kingpin, the front of the truck is lifted. This lifting of the vehicle is experienced as steering effort when the turn is executed and exhibits itself as recovery force when the steering wheel is released.



### FIGURE 8-4




**Kingpin Offset** — The distance between the center of the tire patch and intersection of the kingpin axis with the ground. This parameter of front end geometry is important in vehicles without power steering and has a major effect on static steering. If there is no kingpin offset, the tires must scrub around the center of the pin patch when turned in a static condition, resulting in higher static steering efforts.

**Steering Arm** — The component that connects the drag link to the axle knuckle assembly.

### Thrust Angle, Tracking, or Square

— The angle formed by the centerline of the vehicle frame (geometric centerline) and the direction that an axle points. As indicated by the term "square", the ideal value for the angle is 0° or when the axle centerline is at




90° or perpendicular to the geometric centerline. Thrust or tracking to the right is positive, and to the left is negative.


A steering correction is required to offset the effect of the thrust angles and keeps the vehicle traveling in a straight line. It results in a lateral offset between the steer and drive axle tires commonly referred to as "dog tracking."

**Tie Rod Arm (lower steering knuckle, cross tube arm)** — The component that transmits steering forces between left and right axle knuckle assemblies through the cross tube assembly.

### FIGURE 8-6




**Toe-in** — is when the horizontal line intersects in front of the wheels, or the wheels are closer together in front than in the back. Toe-in is commonly designated as positive, toe-out as negative. Excessive toe-in wears the outside edge of the tires. Steer axle toe is adjustable to reduce wear to the leading edge of the tire and also to avoid road wander. Toe is adjusted in a static, unloaded condition so that the tires will run in a straight line under a dynamic, loaded condition.



**Toe-out** — Is when the horizontal lines intersect behind the wheels, or the wheels are closer together in back than in front. Toe-in is commonly designated as positive, toe-out as negative. Excessive toe-out wears the inside edge of the tires. Steer axle toe is adjustable to reduce wear to the leading edge of the tire and also to avoid road wander. Toe is adjusted in a static, unloaded condition so that the tires will run in a straight line under a dynamic, loaded condition.

**Toe-Out on Turns** — (See Ackermann Geometry). Excessive turning angles such as those encountered in pickup and delivery operations may contribute to premature tire wear. Be advised that the greater turning angles, the more that toe and camber change. If you have any doubt regarding the optimum turning angles for your operation, contact the vehicle's manufacturer, axle manufacturer, tire manufacturer and alignment equipment manufacturer for advice.

**Total Toe** — The angle formed by two horizontal lines through the planes of two wheels. Steer axle toe Is adjustable to reduce wear to the leading edge of the tire and also to avoid road wander. Toe is adjusted in a static, unloaded condition so that the tires will run in a straight line under a dynamic, loaded condition.





## INSPECTION PRIOR TO ALIGNMENT

# WHEELS AND TIRES

Examine the following items:

- The tires are inflated to the manufacturer's specified tire pressure.
- The steer axle tires are the same size and type.
- The lug nuts are tightened to manufacturer's specified torque.
- The wheels are balanced and check for tire to rim runout.
- The wheels and tires are free of excessive wear and damage.
- Wheel bearing end play is within vehicle manufacturer's specification.

### FRONT SUSPENSION

Inspect the following:

- All fasteners are installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the specified torque, refer to the <a>Installed and tightened to the <a>Installed and <a>Installed and <a>I
- Leaf springs are free of wear or damage.
- Shock absorbers are free of wear and damage.
- Front and rear spring mounts for wear or damage.

### **TIE ROD ENDS**

Perform the Tie Rod Inspection procedure, refer to the Preventive Maintenance section of this publication.

### **REAR AXLE AND REAR SUSPENSION**

Rear axle misalignment can cause front tire wear. If the outer edge of one front tire is worn and the inner edge of the other front tire is worn, check the following:

- Ensure the rear axle is correctly aligned. Refer to the procedure from the vehicle or suspension manufacturer.
- All fasteners, including U-bolts (if applicable) are installed and tightened to the specified torque.
- Ensure the leaf springs are not worn or damaged.
- Ensure the bushings in the leaf springs are not worn or damaged.
- Verify the frame is not bent or twisted.
- Refer to any additional recommendations and specifications from the manufacturer of vehicle on rear axles and suspensions.

### FRONT WHEEL ALIGNMENT

Hendrickson recommends technicians review the TMC Guidelines for Total Vehicle Alignment (TMC RP 642).

Check total (front and rear) vehicle wheel alignment when any of the following occurs:

- Every 50,000 to 80,000 miles (80,467 to 128,747 kms), or 12 to 18 months, whichever comes first.
- When the vehicle does not steer correctly.
- To correct a tire wear condition.

For **rear** wheel alignment specifications and adjustment refer to the vehicle manufacturer.

The **front** wheel alignment specifications can be found in the Alignment section of this publication. There are two types of front wheel alignment:

 Minor alignment – a minor front wheel alignment is done for all normal maintenance conditions, see below.



2. **Major alignment** – a major alignment is done when uneven or excessive tire wear is evident, or response at the steering wheel is sluggish, or the need for major wheel alignment check and adjustment is required, see below.

### MINOR FRONT WHEEL ALIGNMENT

Perform the minor front wheel alignment in the following sequence:

- 1. Inspect all systems that affect wheel alignment. Refer to Inspection Prior to Alignment in this section.
- 2. Check the wheel bearing end play.
- 3. Check and adjust toe if necessary.

### **MAJOR FRONT WHEEL ALIGNMENT**

Be certain to follow wheel alignment inspection intervals as specified by the vehicle manufacturer. Before performing a major front wheel alignment it is recommended that alignment equipment calibration be checked to ensure proper vehicle alignment.

Major wheel alignment is accomplished in the following sequence of operation:

- 1. Inspect all the systems that influence the wheel alignment. Refer to the Inspection Prior to Alignment in this section.
- 2. Check and adjust the maximum turn angle, refer to the Steering Stop Adjustment Procedure in this section, see Figures 8-9 and 8-10.
- 3. If the vehicle is equipped with power steering, check the pressure relief in the power steering system and reset if necessary. Refer to the vehicle manufacturer regarding the subject: Adjusting the Pressure Relief in the Power Steering System.

FIGURE 8-9



FIGURE 8-10



- 4. Check the turning angle. Refer to the original equipment manufacturer specifications.
- 5. Check the kingpin (or steering axis) inclination. Refer to Kingpin Inclination under Alignment Definitions in this section.

**WARNING** 

AXLE CAMBER IS NOT ADJUSTABLE. DO NOT CHANGE THE AXLE CAMBER ANGLE OR BEND THE AXLE BEAM. BENDING THE AXLE BEAM TO CHANGE THE CAMBER ANGLE CAN DAMAGE THE AXLE AND REDUCE AXLE STRENGTH, AND WILL VOID HENDRICKSON'S WARRANTY. A BENT AXLE BEAM CAN CAUSE LOSS OF VEHICLE CONTROL, POSSIBLY CAUSING PERSONAL INJURY OR PROPERTY DAMAGE, SEE FIGURE 8-11.



UNAUTHORIZED TAMPERING OF STEERTEK NXT INTEGRATED AXLE SPRING SEATS CAN CAUSE COMPONENT AND STRUCTURAL DAMAGE AND RESULT IN LOSS OF VEHICLE CONTROL, SEVERE PERSONAL INJURY OR DEATH, PROPERTY DAMAGE, AND WILL VOID ANY APPLICABLE WARRANTY, SEE FIGURE 8-11.


- DO NOT REMOVE, MODIFY OR REPLACE INTEGRATED AXLE SPRING SEAT OR FASTENERS.
- 6. Check the camber angle. **DO NOT** attempt to adjust. Refer to Camber in the Alignment Definitions in this section.



NOTE

Contact Hendrickson Tech Services for any questions regarding STEERTEK NXT integrated axle spring seats and / or fasteners.

#### FIGURE 8-11



- 7. Check and adjust caster angle. Refer to "Caster" in the Alignment Definitions in this section. **The use of two (2) different angle caster shims will not change cross caster.** Cross caster is the difference between the caster readings for left and right side of the vehicle.
- 8. Check and adjust toe-in, refer to Toe Setting in this section.

### **STEERING STOP**

### **ADJUSTMENT PROCEDURE**

When the axle or lower steering knuckle is replaced, the steering stop adjustment must be checked.

- 1. Drive the vehicle on turntables and chock the rear wheels.
- Measure the wheel cut. The wheel cut
  is determined by steering the tires.
  Wheel cut is measured at the inside
  wheel only, therefore the tires must
  be turned to the full lock position for
  each right hand and left hand direction. Refer to the vehicle manufacturer
  for exact specifications.
- 3. Increase the wheel cut by loosening the jam nuts and screw the stop bolts clockwise.
- 4. Tighten the jam nuts.



NOTE

It is very important that the sides of the square head stop bolts are set parallel to the axle beam to ensure a good contact point on the axle, see Figure 8-12.

- 5. Decrease the wheel cut by loosening the jam nuts and screw the stop bolts counter-clock-wise.
- 6. Tighten the stop bolts to  $3.50 \pm 10$  foot pounds torque.
- 7. Measure the wheel cut and check for any interference with related steering components.



ALWAYS CHECK/RESET THE STEERING GEAR BOX POPPET WHEN THE WHEEL CUT IS DECREASED. FOLLOW MANUFACTURER'S GUIDELINES FOR THE GEAR BOX POPPET RESETTING PROCEDURE. FAILURE TO DO SO CAN RESULT IN PREMATURE FAILURE OF THE AXLE OR STEERING KNUCKLE. THIS CONDITION CAN CAUSE LOSS OF VEHICLE CONTROL, POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE AND VOID ANY APPLICABLE WARRANTY.



### **TOE SETTING**

- 1. Place the vehicle on a level floor with the wheels in a straight ahead position.
- 2. Raise the vehicle and support the front axle with safety stands.
- 3. Chock the rear wheels of the vehicle.
- 4. Use paint and mark the center area of tread on both steer axle tires around the complete outer diameter of the tires.
- 5. Scribe a line through both steer axle tires in the painted area around the complete outer diameter of the tires.
- 6. Raise the vehicle and remove the safety stands.
- 7. Set the vehicle on the ground.


NOTE

DO NOT measure toe-in with the front axle off the ground. The weight of the vehicle must be on the front axle when toe-in is measured.

- 8. Use a trammel bar and measure the distance between the scribe marks at the rear of the steer axle tires. Record the measurement.
- 9. Install the trammel bar and measure the distance between the scribe marks at the front of the steer axle tires. Record the measurement, see Figure 8-13.

NOTE

When setting up the trammel bar the pointers should be level with the spindles at the front and rear of the steer axle tires.



- 10. To calculate the toe setting subtract the front measurement from the rear measurement, the difference between the two will equal the toe-in/toe-out measurement.
- 11. If the toe measurement is not within the specifications of  $\frac{1}{6}$ "  $\pm \frac{1}{32}$ " (0.060"  $\pm 0.030$ "), it will be necessary to adjust the toe setting as per the following procedure.
  - a. Loosen the tie rod cross tube clamp bolts and locknuts.
  - b. Turn the tie rod cross tube until the specified toe-in distance is achieved.
  - c. Tighten the bolt and locknut on the tie rod cross tube to  $\bigcirc 368 \pm 7$  foot pounds torque.




# **WARNING**

THE THREADED PORTION OF THE TIE ROD END MUST EXTEND PAST THE SLOTS INTO THE TIE ROD (SEE FIGURE 8-14) IT IS CRITICAL TO CHECK THE ½"TIE ROD CLAMP BOLT HEAD LOCATION TO VERIFY THE CLAMP FASTENERS HAVE SUFFICIENT CLEARANCE AWAY FROM THE LOWER SHOCK MOUNT AT FULL WHEEL CUT. THE FASTENERS MUST NOT CONTACT THE LOWER SHOCK MOUNT. FAILURE TO DO SO CAN CAUSE ONE OR MORE COMPONENTS TO FAIL CAUSING LOSS OF VEHICLE CONTROL AND POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE.

- 12. Verify the tie rod clamp bolt head does not contact the lower shock mount at full wheel cut, see Figure 8-14.
- 13. Repeat Steps 1-10 until the correct toe setting is achieved.
- 14. Remove the vehicle frame safety stands and lower the vehicle.
- 15. Remove the rear wheel chocks.

### FIGURE 8-14



### 1/2" Tie Rod Clamp Bolt

It is critical to check the ½" tie rod clamp bolt head location to verify the clamp fasteners have sufficient clearance away from the lower shock mount at full wheel cut. The fasteners must not contact the lower shock mount.

### Tie Rod Cross Tube Slots

It is critical to have the threaded portion of the tie rod end extend past the slots in the tie rod cross tube.


½"Tie Rod Clamp Locknut Tightening Torque 68 ± 7 ft. lbs. (92 ± 9 Nm)

## **LEAF SPRING EYE RE-TORQUE**

NOTE

This procedure to re-torque is necessary when replacing the: front hanger, shackle assembly and the leaf spring assembly

# **RE-TORQUE PROCEDURE**



1. Chock the rear wheels of the vehicle to prevent movement.

### **NOTE**

# DO NOT remove the spring eye bolts.

- 2. Loosen all six (6) front and rear spring eye bolts.
- 3. Let the suspension settle.

# FIGURE 8-16





# SOFTEK® Front Suspension for Workhorse W56 Electric Step Vans

- 4. Tighten spring eye bolt 3/4" locknuts (see Figure 8-15):
  - Front to  $330 \pm 10$  foot pounds torque
  - Rear to  $370 \pm 10$  foot pounds torque
- 5. Affix a straight edge to the bottom of the frame rail in front of the leaf spring, see Figure 8-16.
- 6. With the vehicle on a level surface measure the distance from the top of the straight edge to the ground on both sides of the vehicle and record the measurements.
- 7. Measure the difference from one side to the other.
- 8. Do a road test and repeat measurement Steps 6 to 8.
- 9. If the measurement is less than 3%" the vehicle is level. If measurement is more than 3%" contact Hendrickson Tech Services.

# WHEEL END AND HYDRAULIC DISC BRAKE ASSEMBLIES AND COMPONENTS

**NOTE** 

Wheel end hubs, seals, bearing cones, hub caps, as well as hydraulic disc brake assemblies and components are installed by Hendrickson for new production assembly but these components are not supplied by Hendrickson for aftermarket service purposes. For more information and assistance with service, maintenance and rebuild instructions on these items see the below listed component manufacturers. Refer to the Parts Lists section of this publication for additional information on such assemblies and components.

- Bosch technical and parts support 888.715.3616 or online www.boschautoparts.com
- DRiV Incorporated parts support 800.325.8886 or online www.drivparts.com
- SKF parts support 800.533.6563, e-mail: vsm.aftermarket.custsrv@skf.com, website: vehicleaftermarket.skf.com
- The Timken Company technical and parts support 866.984.6536 or online www.timken.com
- Webb Wheel Products technical and part support 800.633.3256 or online www.webbwheel.com



# **SECTION 9**

# Component Replacement



### **ELECTRIC VEHICLE SAFETY**

PRIOR TO PERFORMING ANY WORK ON THE VEHICLE, READ ALL WORK INSTRUCTIONS AND SAFETY INFORMATION PROVIDED BY THE VEHICLE MANUFACTURER AND MAKE SURE THAT THE STARTER SWITCH IS IN THE "OFF" POSITION, SET THE PARKING BRAKE, AND CHOCK THE TIRES.

TOOLS USED WHEN WORKING NEAR BATTERIES OR ELECTRICAL CONNECTIONS MUST BE CERTIFIED TO A RATING OF 1000 VDC TO HELP PREVENT INJURIES FROM ELECTRIC SHOCK. SHORT CIRCUITS BETWEEN COMPONENTS OR WIRES MUST BE AVOIDED.

### **FASTENERS**

Hendrickson recommends that when servicing the vehicle to replace the removed fasteners with new equivalent fasteners. Maintain correct torque values at all times. Check torque values as specified. See Hendrickson's Torque Specifications section of this publication. If non-Hendrickson fasteners are used follow torque specifications listed in the vehicle manufacturer's service manual.


### FRONT LEAF SPRING EYE BUSHINGS

The spring eye bushings for the SOFTEK leaf spring is designed to provide extended service life. If premature wear occurs careful consideration must be given to the contributing factor that caused the wear. This must be corrected in order to prevent the new bushing from wearing in the same manner. The front and rear bushings are permanently installed in the spring leaf and are not serviceable. If a bushing wears prematurely, the leaf spring assembly must be replaced. Follow the procedure for the Leaf Spring Assembly in this section.

### FRAME HANGER

### DISASSEMBLY

- 1. Place the vehicle on level floor.
- 2. Chock the wheels.
- 3. Raise the frame and support the vehicle with safety stands.
- 4. Remove the wheel assemblies as per the vehicle manufacturer's instructions.
- 5. Suspend the front axle from the shock absorbers.
- 6. Remove and discard the ¾" spring eye fasteners.



### **SERVICE HINT**

A bottle jack may be required to raise the axle slightly to facilitate removal of the spring eye bolt.

- 7. Remove the frame mounting fasteners from the hanger per manufacturer's guidelines.
- 8. Remove the hanger from the vehicle, see Figure 9-1.

### **ASSEMBLY**

- 1. Install the new hanger on the frame.
- 2. Install new frame fasteners per manufacturer's instructions.
- 3. Install the new 3/4" spring eye fasteners, see Figure 9-1.
- 4. Remove the safety stands and lower frame.



- 5. Tighten the  $\frac{3}{4}$ " locknut to  $\boxed{3}$  330  $\pm$  10 foot pounds torque.
- 6. Install the wheel assemblies as per the vehicle manufacturer's instructions.
- 7. Lower the frame.
- 8. Remove the wheel chocks.

# REAR SHACKLE BRACKET

### DISASSEMBLY

- 1. Place the vehicle on level floor.
- 2. Chock the wheels.
- Raise the vehicle frame and support with safety stands.
- 4. Remove the wheel assemblies as per the vehicle manufacturer's instructions.
- 5. Suspend the front axle from the shock absorbers.
- 6. Remove and discard the rear 3/4" spring eye and shackle fasteners.

### SERVICE HINT

A bottle jack may be required to raise the axle slightly to facilitate removal of the spring eye bolt.

- 7. Remove the frame fasteners from the shackle bracket per manufacturer's guidelines.
- 8. Remove the shackle bracket from the vehicle, see Figure 9-2.
- 9. Inspect the shackle bracket and shackle plate for excessive wear or damage.


### **ASSEMBLY**

- 1. Install the shackle bracket on the frame.
- 2. Install new frame fasteners per manufacturer's guidelines.
- 3. Install the shackle plate with the new 3/4" fasteners. Snug the shackle bolts. **DO NOT** tighten at this time.
- 4. Remove the safety stands and lower frame.
- 5. Tighten the  $\frac{3}{4}$ " shackle locknuts to  $\frac{3}{4}$  370 ± 10 foot pounds torque, see Figure 9-2.
- 6. Install the wheel assemblies as per the vehicle manufacturer's instructions.
- 7. Lower the frame.
- 8. Remove the wheel chocks.

### RUBBER AXLE STOP

### **REMOVAL**

- 1. Insert a small pry bar between the rubber stop and the inside of the top pad.
- 2. Apply downward force on the pry bar and pull the rubber stop out of the top pad, see Figure 9-3.
- 3. Inspect the top pad and frame rail flange for any contact damage.
- 4. Clean any debris from inside the top pad.





### **INSTALLATION**

- 1. Lubricate the new rubber axle stop with soapy water.
- 2. Install the rubber axle stop in the top pad.
- 3. Apply downward force on the rubber axle stop until it is seated firmly in the top pad.

### **SHOCK ABSORBER**

NOTE

WARNING

It is not necessary to replace the shock absorber in pairs if only one (1) shock absorber requires replacement.


THE SHOCK ABSORBERS ARE THE REBOUND TRAVEL STOPS FOR THE SPRINGS. ANYTIME THE FRONT AXLE ON SOFTEK SUSPENSION

IS SUSPENDED IT IS MANDATORY THAT THE SHOCK ABSORBERS REMAIN CONNECTED. FAILURE TO DO SO COULD CAUSE THE LEAF SPRINGS TO EXCEED THEIR MAXIMUM LENGTH, OR CAUSE A REVERSE ARCH IN THE STEEL LEAF SPRINGS, POSSIBLY RESULTING IN PREMATURE STEEL LEAF SPRING FAILURE.

### **DISASSEMBLY**


- 1. Place the vehicle on a level floor.
- 2. Chock the wheels.
- 3. Remove and discard the 5%" **lower** mounting fasteners.
- 4. Remove the lower shock absorber spacer, see Figure 9-4.
- 5. Remove and discard the %" upper mounting fasteners.
- 6. Remove the shock absorber out of the lower mounting shock mount.
- 7. Inspect the shock absorber mounting brackets and hardware for damage or wear, replace as necessary.


### FIGURE 9-4



### **ASSEMBLY**

- 1. Install the shock absorber into the upper mounting bracket and install upper fasteners.
- 2. Install the lower taper end of the shock absorber spacer facing the shock absorber and the opposite side facing the lower shock absorber mount, see Figure 9-4.
- 3. Install the lower shock absorber bolt from the outboard side to the inboard side of the leaf spring assembly.
- 4. Install the lower shock absorber fasteners, see Figure 9-4.
- 5. Tighten both upper and lower 5/8" fasteners to  $\P$  95 ± 5 foot pounds torque, see Figure 9-4.
- 6. Remove wheel chocks.







## **LEAF SPRING ASSEMBLY**

### NOTE

The leaf spring assembly replacement procedure is done on one side with the other leaf spring assembly attached.

### DISASSEMBLY

- 1. Place the vehicle on a level floor.
- 2. Chock the wheels.
- 3. Raise the vehicle and support with safety stands. It may be necessary to remove the peripheral components for installation of the safety stands.
- 4. Remove the wheel assemblies as per the vehicle manufacturer's instructions.
- 5. Install a floor jack with a 4 inch plate below the axle and raise the axle.
- Lower the floor jack to remove the load on the leaf spring assembly (keep jack on axle, **DO NOT** remove).
- 7. Remove and discard **front** spring eye fasteners from the side being serviced per the vehicle manufacturer's instructions.

### **SERVICE HINT**

To ease in the removal of the leaf spring eye bolts, it may be necessary to raise or lower the axle slightly.

- 8. Remove and discard the **rear** shackle pivot bolt fasteners from the side being serviced.
- 9. Remove and discard the lower shock absorber mounting fasteners from the side being serviced.
- Loosen, DO NOT remove, the clamp group locknuts for the opposite leaf spring assembly that is not being serviced.



DO NOT USE A CUTTING TORCH TO REMOVE CLAMP GROUP BOLTS OR ATTACHING FASTENERS. THE USE OF SUCH HEAT ON SUSPENSION COMPONENTS CAN ADVERSELY AFFECT THE STRENGTH OF THESE PARTS. A COMPONENT DAMAGED IN THIS MANNER CAN RESULT IN THE LOSS OF VEHICLE CONTROL AND POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE.

### SERVICE HINT

If a clamp group locknut fails to come off the bolt, cut half way through the bolt with an abrasive cut off wheel, taking care not to contact axle beam or other components. Using an impact wrench, spin the locknut to fracture the bolt and remove.

- 11. On the side being serviced, remove and discard the clamp group U-bolts and fasteners.
- 12. From the side being serviced, remove the top pad from the leaf spring assembly, see Figure 9-5.
- 13. Lower the floor jack to allow enough clearance to remove the leaf spring assembly from the frame hanger.
- 14. Remove the leaf spring assembly.

#### **ASSEMBLY**

## **SERVICE HINT**

To ease in the installation of the leaf spring eye bolts, it may be necessary to raise or lower the axle slightly.

- 1. Install the new leaf spring assembly on the axle.
- 2. Verify that the center bolt is engaged properly in the axle spring seat
- 3. Install the top pad and verify the center bolt is engaged in the top pad, see Figure 9-5.

## NOTE

Ensure the part number on top pad is positioned on outboard side of the vehicle, see Figure 9-6.

### **NOTE**

New clamp group fasteners must be used when the clamp group is removed, to prevent premature bolt fatigue.


4. Install new clamp group fasteners and snug the clamp group, **DO NOT** tighten to torque at this time.



Top Pad Part Number

must be positioned on outboard side

of the vehicle




- 5. Install the **FRONT** spring eye bolt and fastener, snug but **DO NOT** tighten at this time.
- 6. Raise the axle and the **REAR** spring eye into the rear shackle bracket.
- 7. Install the **REAR** spring eye bolts in the rear shackle bracket, snug but **DO NOT** tighten at this time, see Figure 9-5.
- 8. Install the shock absorber, refer to Shock Absorber in this section. **DO NOT** tighten the lower shock absorber fasteners at this time.
- 9. Raise the vehicle and remove the safety stands.
- 10. Place two safety stands under the axle to load the front axle and then lower the vehicle.
- 11. Tighten the lower shock mounting fasteners to  $\P$  95 ± 5 foot pounds torque.
- 12. Tighten the:
  - Front spring eye fasteners to  $330 \pm 10$  foot pounds torque.
  - Rear spring eye fasteners to  $370 \pm 10$  foot pounds torque.


**A** WARNING

ENSURE THE CLAMP GROUP IS ALIGNED PROPERLY PRIOR TO TIGHTENING HARDWARE. FAILURE TO DO SO CAN CAUSE LOSS OF VEHICLE CONTROL, PROPERTY DAMAGE OR PERSONAL INJURY.

- 13. Ensure that the clamp group is properly aligned, and the U-bolts are seated in top pad, see Figure 9-7.
- 14. Tighten the clamp group fasteners evenly in 50 foot pounds increments to  $3 180 \pm 15$  foot pounds torque in the proper pattern to achieve uniform bolt tension, see Figure 9-8.
- 15. Install the wheel assemblies per the vehicle manufacturer's instructions.
- 16. Remove the wheel chocks.







#### STEERTEK NXT AXLE

#### STEERTEK NXT AXLE REMOVAL

Refer to Figure 9-9 when replacing STEERTEK NXT axle components.

- 1. Place the vehicle on level floor.
- 2. Chock the wheels.
- 3. Raise the frame and support the vehicle with safety stands.
- 4. Suspend the front axle with the shock absorbers attached.



THE INTEGRATED AXLE SPRING SEATS ON THE STEERTEK NXT AXLE ARE NON-SERVICEABLE. UNAUTHORIZED TAMPERING OF INTEGRATED AXLE SPRING SEATS CAN CAUSE COMPONENT AND STRUCTURAL DAMAGE AND RESULT IN LOSS OF VEHICLE CONTROL, SEVERE PERSONAL INJURY OR DEATH, PROPERTY DAMAGE, AND WILL VOID ANY APPLICABLE WARRANTY. DO NOT REMOVE, MODIFY OR REPLACE INTEGRATED AXLE SPRING SEAT OR FASTENERS, SEE FIGURE 3-1.

- 5. Remove the front wheel end assemblies per the vehicle manufacturer's instructions.
- 6. Disconnect the drag link from the steering arm.
- 7. Support the axle with safety stands.



DO NOT USE A TORCH ON CLAMP GROUP BOLTS OR ANY OTHER PART OF THE SOFTEK SUSPENSION. IF THE CLAMP GROUP BOLTS WILL NOT COME LOOSE WITH AN IMPACT WRENCH, USE A CUT OFF WHEEL AND CUT THE SHANK OF THE BOLT. THE USE OF A TORCH CAN CAUSE DAMAGE TO CERTAIN SOFTEK COMPONENTS THAT CAN RESULT IN THE LOSS OF VEHICLE CONTROL AND POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE.

#### **SERVICE HINT**

If a clamp group locknut fails to come off the bolt, cut half way through the bolt with an abrasive cut off wheel, taking care not to contact axle beam or other components. Using an impact wrench, spin the locknut to fracture the bolt and remove.

- 8. Remove and discard the 5/8" clamp group fasteners.
- 9. Lower the axle and remove axle assembly from the vehicle.

#### **AXLE DISASSEMBLY (Removed from Chassis)**

1. Remove the tie rod assembly. See Tie Rod in this section.




PRIOR TO REMOVAL OF THE SOCKET HEAD STOP BOLTS SUPPORT THE LOWER STEERING KNUCKLE, FAILURE TO DO SO CAN CAUSE COMPONENT DAMAGE OR PERSONAL INJURY. REMOVAL OF THE SOCKET HEAD STOP BOLTS WILL ALLOW THE STEERING KNUCKLE TO SEPARATE FROM THE AXLE.

- 2. Remove and discard the two (2) socket head stop bolts from the steering knuckle assembly with the lower steering knuckle supported, see Figure 9-9.
- 3. Remove the steering knuckles and thrust bearings.
- 4. After complete removal of the one side, repeat steps 1-3 for the opposite side of the axle.



5. Inspect the steering kingpin bushings for excessive wear. If worn, replace the kingpin bushings and seals. See the Kingpin Bushing in this section.

FIGURE 9-9



#### STEERTEK NXT AXLE INSTALLATION


- 1. Place the new axle on the floor jack and position the axle under the vehicle, see Figure 9-10.
- 2. Raise the axle into position.
- 3. Ensure the front leaf spring assembly's center bolt is aligned correctly in the axle spring seat, see Figure 9-10.
- 4. Install the new clamp group fasteners. **DO NOT** tighten to torque at this time.




ENSURE THE CLAMP GROUP IS ALIGNED PROPERLY PRIOR TO TIGHTENING HARDWARE. FAILURE TO DO SO CAN CAUSE LOSS OF VEHICLE CONTROL, PROPERTY DAMAGE OR PERSONAL INJURY.

5. Ensure the clamp group is properly aligned and the U-bolts are seated in the top pad, and the top pad is centered on the axle spring seat, see Figure 9-11.





- 6. Install the steering knuckles, see Steering Knuckle in this section.
- 7. Install the tie rod assembly, see Tie Rod End and Cross Tube in this section.
- 8. Connect the drag link in the steering arms per the vehicle manufacturer's instructions.
- 9. Install the wheel end assemblies as per the vehicle manufacturer's instructions.
- 10. Raise the vehicle and remove the safety stands.
- 11. Lower the floor jack and load the front axle with the vehicle's weight.
- 12. Remove the floor jack.
- 13. Tighten the clamp group locknuts evenly in 50 foot pounds increments to  $3 \times 180 \pm 15$  foot pounds torque in the proper pattern to achieve uniform bolt tension, see Figure 9-12.
- 14. Remove the wheel chocks.
- 15. Fill the hubs with the proper lubricant (see manufacturer's guidelines for recommended lubrication specifications).
- 16. Grease the front steering components as per lubrication guidelines in the Preventive Maintenance section of this publication.





#### STEERING KNUCKLE DISASSEMBLY

#### NOTE

Steering knuckle component replacement includes kingpin preparation and measurement, kingpin bushing removal, steering knuckle bore measurement, kingpin bushing installation, reaming, and kingpin seal installation.

#### You will need:

- Kingpin bushing and seal installer/remover, driver and receiver tool Adjustable straight flute reamer, refer to the Special Tools section of this publication
- A hydraulic shop press with a minimum forcing capacity of 2.5 tons (or an arbor press) or optional method use hand tools Vise with brass jaws (soft jaws)

#### NOTE

Note the orientation of steering arm before removal.

- 1. Place the vehicle on level floor.
- 2. Chock the wheels.
- 3. Support the vehicle with safety stands.
- 4. Raise and support the axle with safety stands.
- 5. Remove the wheel end assemblies per the vehicle manufacturer's instructions.



DO NOT USE A PICKLE FORK STYLE TOOL TO SEPARATE THE TIE ROD END FROM THE STEERING KNUCKLE ARM. DOING SO WILL RESULT IN DAMAGE TO THE GREASE BOOT.

- 6. Remove the tie rod assembly, refer to Tie Rod End and Cross Tube in this section.
- 7. Remove the drag link from the knuckle if necessary per the vehicle manufacturer's instructions.



REMOVAL OF THE SOCKET HEAD CAP SCREWS WILL ALLOW THE STEERING KNUCKLE TO SEPARATE FROM THE AXLE. THE STEERING KNUCKLE MUST BE SUPPORTED BEFORE REMOVAL OF THESE TWO BOLTS, FAILURE TO DO SO CAN CAUSE COMPONENT DAMAGE OR PERSONAL INJURY.

8. Remove the two socket head cap screws that connect the upper kingpin connection to the steering knuckle, see Figure 9-13.

#### **SERVICE HINT**

Remove the grease zerks from the knuckle assemblies. This will allow the knuckle assemblies to freely slide up and down the kingpins without creating back pressure.

- 9. Remove the grease zerks from the knuckle assemblies.
- Remove the lower steering knuckle from the kingpin by sliding it down the kingpin.
- 11. Remove the upper steering knuckle by sliding it up off the kingpin.







#### KINGPIN PREPARATION AND MEASUREMENT

#### Cleaning the Ground and Polished Parts

- Use a cleaning solvent to clean ground or polished parts and surfaces. DO NOT USE GASOLINE.
- **DO NOT** clean ground or polished parts in a hot solution tank or with water, steam, or alkaline solutions. These solutions will cause corrosion of the parts.

#### Cleaning the Rough Parts

Rough parts can be cleaned with the ground or polished parts. Rough parts can also be cleaned in hot solution tanks with a weak alkaline solution. The parts must remain in the hot solution tanks until they are completely cleaned and heated.

### **Drying the Cleaned Parts**

Parts must be dried immediately after cleaning. Dry the parts with clean paper towels, clean rags, or compressed air. DO NOT dry bearings by spinning with compressed air. Damage to the bearings will result.

#### **Preventing Corrosion on Cleaned Parts**

Apply a light coating of oil to all cleaned and dried parts that are going to be reused. **DO NOT** apply oil to the brake lining. If parts are to be stored, apply an effective rust inhibitor to all surfaces.



TO HELP PREVENT SERIOUS EYE INJURY, ALWAYS WEAR PROPER EYE PROTECTION WHEN YOU PERFORM VEHICLE MAINTENANCE OR SERVICE.



SOLVENT CLEANERS CAN BE FLAMMABLE, POISONOUS AND CAUSE BURNS. TO HELP AVOID SERIOUS PERSONAL INJURY, CAREFULLY FOLLOW THE MANUFACTURER'S PRODUCT INSTRUCTIONS AND GUIDELINES AND THE FOLLOWING PROCEDURES:

- WEAR PROPER EYE PROTECTION
- WEAR CLOTHING THAT PROTECTS YOUR SKIN
- WORK IN A WELL VENTILATED AREA
- DO NOT USE GASOLINE. SOLVENTS OR OTHER MATERIALS THAT CONTAIN GASOLINE THAT CAN EXPLODE
- HOT SOLUTION TANKS OR ALKALINE SOLUTIONS MUST BE USED CORRECTLY. FOLLOW THE MANUFACTURER'S RECOMMENDED INSTRUCTIONS AND GUIDELINES CAREFULLY TO HELP PREVENT PERSONAL ACCIDENT OR INJURY.



DO NOT USE HOT SOLUTION TANKS OR WATER AND ALKALINE SOLUTIONS TO CLEAN GROUND OR POLISHED PARTS. DAMAGE TO THE PARTS WILL RESULT.



THE STEERTEK NXT HAS A UNIQUE AXLE. THE KINGPIN IS CRYOGENICALLY INSTALLED IN THE AXLE. THE KINGPIN IS A NON-REPLACEABLE COMPONENT OF THE AXLE ASSEMBLY. DO NOT TRY TO REMOVE THE KINGPIN. DOING SO WILL DAMAGE THE AXLE AND MAY CAUSE LOSS OF VEHICLE CONTROL, PERSONAL INJURY OR PROPERTY DAMAGE. IF THE KINGPIN SHOWS SIGNS OF MOVEMENT, CONTACT HENDRICKSON TECH SERVICES.

1. Prepare and polish the kingpin by removing all grease and excess debris using a fine grit (220 grit or higher) emery cloth and parts solvent, see Figures 9-14 through 9-17.

FIGURE 9-14



FIGURE 9-15





FIGURE 9-16



FIGURE 9-17



2. Inspect the kingpin for wear or damage. Use a micrometer and measure the upper and lower kingpin in two locations. Positions must be 90° opposed from each other. If the kingpin has less than 1.351" diameter, replacement of the axle is necessary, see Figures 9-18 through 9-21.

#### Kingpin minimum dimension is 1.351

FIGURE 9-18



FIGURE 9-19



FIGURE 9-20



FIGURE 9-21



#### KINGPIN BUSHING

#### You will need:

- A hydraulic shop press with a minimum forcing capacity of 2.5 tons (or an arbor press) or use hand tools. Note If a shop press is not available to remove / install the kingpin bushings. An acceptable optional method is to use a hammer along with the shop made tools on a work bench.
- Kingpin bushing and seal installer/remover, driver and receiver tool, refer to the Special Tools section of this publication.

NOTE

If one (1) bushing is worn or damaged, it is mandatory to replace both the upper and lower bushings on that knuckle assembly.



BEFORE APPLYING HYDRAULIC PRESSURE TO ANY TOOLING SET-UP, ALWAYS CHECK TO ENSURE THE PRESS PLATE, TOOLS, AND COMPONENTS BEING WORKED ON ARE POSITIONED PROPERLY, I.E. "IN LINE" WITH THE RAM OF THE PRESS. IMPROPER POSITIONING CAN CAUSE PERSONAL INJURY OR COMPONENT DAMAGE.



PRIOR TO APPLYING HYDRAULIC PRESSURE TO REMOVE OR INSTALL THE KINGPIN BUSHING, SUPPORT THE LOWER STEERING KNUCKLE AS SHOWN IN FIGURE 9-21. IMPROPER SUPPORT TO THE STEERING KNUCKLE CAN CAUSE COMPONENT DAMAGE.

#### **REMOVAL**

NOTE

To remove the kingpin bushing, always drive the bushing from the **non-machined side** of the upper or lower steering knuckle.

- 1. Remove the threaded grease cap and grease zerk.
- Place the machined surface of the steering knuckle face down (axle side down), ensure each part
  of the steering knuckle assembly is squarely supported on the bushing receiving tool before applying
  hydraulic pressure to press out the kingpin bushings, see Figures 9-22 and 9-23.



FIGURE 9-22



**FIGURE 9-23** 



FIGURE 9-24



FIGURE 9-25



- 3. From the **non-machined surface** of the upper or lower steering knuckle, use the kingpin bushing installer/remover tool to drive the kingpin bushing and kingpin seal out of the steering knuckle, see Figure 9-24.
- 4. Clean the parts and inspect for reassembly, see Figure 9-25.

#### STEERING KNUCKLE BORE MEASUREMENT

Complete the following steering knuckle bore inspection and the measurement instructions prior to installing the kingpin bushing.

- 1. Measure the upper and lower steering knuckle bores inside diameter at two positions and two locations. The two positions must be 90° opposed from each other, see Figures 9-26 through 9-28. Always use an inside micrometer or a telescoping gauge when taking a knuckle bore measurement. Some out-of-roundness at the top and bottom of the bore edges is acceptable. Steering knuckle bore diameter is 1.486" ± 0.001".
  - If the average measurement is more than the knuckle bore maximum diameter specification, steering knuckle replacement is necessary.

FIGURE 9-26



**FIGURE 9-27** 



**FIGURE 9-28** 



#### KINGPIN BUSHING INSTALLATION

NOTE

To install the kingpin bushing, always drive the bushing from the machined side of the steering knuckle.



BEFORE APPLYING HYDRAULIC PRESSURE TO ANY TOOLING SET-UP, ALWAYS CHECK TO ENSURE THE PRESS PLATE. TOOLS, AND COMPONENTS BEING WORKED ON ARE POSITIONED PROPERLY, I.E. "IN LINE" WITH THE RAM OF THE PRESS, IMPROPER POSITIONING CAN CAUSE PERSONAL INJURY OR COMPONENT DAMAGE.

- 1. Place the **machined surface** of the upper/lower steering knuckle **face up** (axle side up), ensure that each part of the steering knuckle assembly is squarely supported before applying hydraulic pressure to press in the kingpin bushing, see Figure 9-29.
- 2. From the machined surface of the steering knuckle, use the kingpin bushing driver tool to drive the kingpin bushing flush into steering knuckle, see Figure 9-30.



- 3. Next, use the kingpin bushing installer/remover tool to sink the kingpin bushing into the steering knuckle bore to just below the seal bore, see Figure 9-31 and 9-32.
- 4. Following this procedure it is necessary to ream the kingpin bushings to fit the kingpins, see Kingpin Bushing Reaming.


**FIGURE 9-29** 



FIGURE 9-30

FIGURE 9-31

**FIGURE 9-32** 



#### KINGPIN BUSHING REAMING

#### You will need:

Kingpin bushing adjustable straight flute reamer, refer to the Special Tools section of this publication.



REAM THE KINGPIN BUSHINGS WITH AN ADJUSTABLE STRAIGHT FLUTE REAMER, SEE SPECIAL TOOLS SECTION OF THIS PUBLICATION. DO NOT HONE OR BURNISH THE KINGPIN BUSHINGS. HONING OR BURNISHING WILL DAMAGE THE BUSHINGS AND VOID ANY APPLICABLE WARRANTY.



WHEN INSTALLING STEERING KNUCKLE COMPONENTS IN A VISE IT IS NECESSARY TO PROTECT THE MACHINED SURFACES FROM GOUGES OR MARRING BY USING BRASS JAWS (SOFT JAWS). FAILURE TO DO SO CAN CAUSE PREMATURE PART DAMAGE, DAMAGE TO THE STEERING KNUCKLE COMPONENTS, LOSS OF WARRANTY, LOSS OF VEHICLE CONTROL, CAUSING PERSONAL INJURY OR PROPERTY DAMAGE.

1. Install the upper / lower steering knuckle assembly in a vise with brass jaws (soft jaws), see Figures 9-33 and 9-34.

#### SERVICE HINT

It is acceptable to mount the knuckle components in a vise either vertically or horizontally when performing the reaming procedure.

- 2. Install the reamer into the upper / lower steering knuckle until the blades touch the kingpin bushing.
- 3. Rotate the reamer with light downward pressure. Rotate the reamer smoothly. **DO NOT** apply too much pressure, see Figures 9-33 and 9-34.
- 4. Slide the reamer out of the bottom of the upper/lower steering knuckle assembly. If it is necessary to remove the reamer from the top, rotate the reamer opposite of cutting rotation.



FIGURE 9-33 Lower Steering Knuckle in Vise





FIGURE 9-34
Upper Steering Knuckle in Vise



**WARNING** 

PRIOR TO INSTALLATION ENSURE THAT ALL RESIDUAL LOCTITE MATERIAL IS REMOVED FROM THE MOUNTING BOLTS AND THE THREAD BORES IN THE UPPER STEERING KNUCKLES, AND NEW LOCTITE 277 OR EQUIVALENT IS APPLIED TO HELP ENSURE THAT THE BOLTS SUSTAIN THE PROPER TORQUE REQUIREMENT. FAILURE TO DO SO CAN CAUSE LOSS OF VEHICLE CONTROL RESULTING IN PERSONAL INJURY OR PROPERTY DAMAGE.

- 5. Clean and remove all kingpin bushing material from the steering knuckle assembly. Take special attention to remove material from the grease channels and dimples.
- 6. Clean the ½" brake backing plate bolts with a wire wheel and run a tap through the threads of the lower steering knuckle assembly and then flush out with brake cleaner and dry with compressed air.

NOTE

The Hendrickson Genuine part, socket head cap screw comes with a pre-applied Loctite compound.

- 7. Temporarily install the upper / lower knuckle on the kingpin to check for fit.
- 8. Rotate the upper / lower knuckle back and forth to verify there is no binding on the kingpin, see Figure 9-35.
- If the bushing is too tight repeat Steps
   through 8 until the proper clearance is achieved.

Bushing size is to be 0.001" larger than the kingpin size.

10. Proceed to Kingpin Seal installation.







NOTE

#### KINGPIN SEAL INSTALLATION



WHEN INSTALLING STEERING KNUCKLE COMPONENTS IN A VISE IT IS NECESSARY TO PROTECT THE MACHINED SURFACES FROM GOUGES OR MARRING BY USING BRASS JAWS. FAILURE TO DO SO CAN CAUSE PREMATURE PART DAMAGE, DAMAGE TO THE STEERING KNUCKLE COMPONENTS, LOSS OF WARRANTY, LOSS OF VEHICLE CONTROL, CAUSING PERSONAL INJURY OR PROPERTY DAMAGE.

- 1. Place the steering knuckle assembly in a vise with brass jaws (soft jaws), or place on a suitable workbench. The steering knuckle will have the **machined surface** facing up (axle side up).
- 2. Lay the kingpin seal into the bore of the steering knuckle. The seal lip should face outward or toward the axle, see Figure 9-36.

17730-356 Component Replacement



- 3. Use the seal installer tool (see Special Tools section of this publication) and press seal firmly into the steering knuckle assembly.
- 4. Install the double lip kingpin seal until it bottoms out in the kingpin bore, see Figure 9-37.






### STEERING KNUCKLE ASSEMBLY

After replacement of the kingpin bushings it is necessary to re-assemble the steering knuckle assemblies. **DO NOT** substitute aftermarket components when servicing.

- 1. Install the thrust bearing on the lower kingpin with the seal facing up toward axle (the black seal will designate the top side).
- 2. Pack the bushing dimples on the upper and lower steering knuckles with multi purpose Lithium based grease (NLGI Grade 2) before installation.
- 3. Install the upper steering knuckle on the upper arm kingpin.
- 4. Install the lower steering knuckle on the lower kingpin and install the old socket head cap screws loose into the top two (2) threaded holes.
- 5. Install a bottle jack under the lower knuckle and slightly raise the steering knuckle until it is possible to thread in the three (3) brake torque plate bolts by hand. These are for guide purposes only.
- 6. Snug the two (2) socket head cap screws.
- 7. Lower the bottle jack so that all the vertical end play is on the underside of the axle.
- 8. Affix a magnetic base dial indicator on the axle and place the tip of the dial indicator on top of the knuckle assembly, see Figure 9-38.
- 9. Zero the dial indicator.
- 10. Raise the bottle jack until there is NO CLEARANCE between the knuckle assembly and the bottom of the axle, slightly lifting the axle.
- 11. Check the reading on the dial indicator. The specification for vertical travel on the steering knuckle during assembly is 0.008" to 0.011".



- Above 0.011", loosen the socket head cap screws and push down on the knuckle assembly until the proper vertical end play is achieved.
- **Below 0.008"**, loosen the socket head cap screws and **pull up** on the knuckle assembly until the proper vertical end play is achieved.





## SOFTEK® Front Suspension for Workhorse W56 Electric Step Vans

# **WARNING**

PRIOR TO INSTALLATION ENSURE THAT ALL RESIDUAL LOCTITE MATERIAL IS REMOVED FROM THE MOUNTING BOLTS AND THE THREAD BORES IN THE UPPER STEERING KNUCKLE, AND NEW LOCTITE 277 OR EQUIVALENT IS APPLIED TO HELP ENSURE THAT THE BOLTS SUSTAIN THE PROPER TORQUE REQUIREMENT. FAILURE TO DO SO CAN CAUSE LOSS OF VEHICLE CONTROL RESULTING IN PERSONAL INJURY OR PROPERTY DAMAGE.

#### **NOTE**

The Hendrickson Genuine part, socket head cap screw comes with a pre-applied Loctite compound.

- 13. Remove one (1) old socket head cap screw and replace with the new socket head cap screw and snug to preserve vertical travel clearance..
- 14. Remove the second socket head cap screw and replace with a new socket head cap screw.
- 15. Tighten both socket head cap screws to  $\P$  110  $\pm$  10 foot pounds torque.
- 16. Recheck the vertical end play with the dial indicator (Figure 9-38), or a 0.010" feeler gauge.
- 17. Remove the brake spider bolts, they should thread out freely.
- 18. Remove the bottle jack and continue assembling the wheel end assemblies.

#### **IMPORTANT NOTE**


It is critical to apply Loctite to the three (3) brake spider bolts to ensure that these bolts sustain the proper torque requirement of steering knuckle assembly.

19. Apply Loctite to the three (3) brake spider bolts prior to installation into the brake spider. Tighten bolts to  $\boxed{3}$  110  $\pm$  10 foot pounds torque.



DO NOT GREASE THE STEERING KNUCKLES WITHOUT THE BRAKE SPIDER INSTALLED AND TIGHTENED TO THE PROPER TORQUE PER THE BRAKE MANUFACTURER'S SPECIFICATIONS. FAILURE TO DO SO CAN CAUSE COMPONENT DAMAGE RESULTING IN FAILURE AND LOSS OF VEHICLE CONTROL, POSSIBLY CAUSING PERSONAL INJURY OR PROPERTY DAMAGE.


- 20. Install the tie rod end into the lower steering knuckle arm.
- 21. Tighten the castle nuts to  $\P$  95  $\pm$  5 foot pounds torque then advance the castle nut to the next hex face to install the cotter pin. **DO NOT** back off the castle nut to install cotter pin.
- 22. Install the drag link into the steering arm and tighten to the vehicle manufacturer's specifications.
- 23. Install new grease caps. Note the grease caps on the STEERTEK NXT axle are threaded, tighten to \$\struct\$\$ 60 \pm 10 foot pounds torque, see Figure 9-39.
- 24. **Allow 30 minutes** for thread sealant to cure before greasing.
- 25. Ensure the kingpin bushing is installed properly below the kingpin seal. Push kingpin seal up against the machined bore face to minimum 0.25 mm, see Figure 9-40.



- 26. Install new grease zerk and thread until it bottoms out to within 1.2 mm maximum gap between hex and steering knuckle surface, see Figure 9-41.
- 27. Install the wheel assemblies per the vehicle manufacturer's instructions.
- 28. Raise the vehicle and remove the safety stand supports.
- 29. Lower the vehicle.
- 30. Grease steering knuckles with the vehicle on the floor.
- 31. Remove the wheel chocks from the vehicle.

17730-356 47 Component Replacement





### TIE ROD END AND CROSS TUBE

#### You will need:

■ ¾"–16 tie rod end removal tool (see Figure 9-42)

#### **DISASSEMBLY**

- 1. Chock the wheels.
- 2. Position the steer axle tires straight ahead.
- 3. Remove the cotter pin and castle nut, see Figure 9-43.
- 4. Use a ¾"-16 tie rod end removal tool to separate the tie rod end from the steering knuckle arm.

  FIGURE 9-43
- 5. Repeat Steps 3 and 4 to remove the other tie rod end to remove the tie rod assembly.
- 6. Remove the tie rod assembly from the vehicle.
- 7. Mount the cross tube in a soft jaw vice.
- 8. Remove the tie rod clamp hardware from the cross tube.
- 9. Count the exposed threads on the tie rod end being replaced.

DO NOT HEAT THE CROSS TUBE WITH A TORCH TO FACILITATE THE REMOVAL OF THE TIE ROD END. THE USE OF SUCH HEAT CAN ADVERSELY AFFECT THE STRENGTH OF THE CROSS TUBE. A COMPONENT DAMAGED IN THIS MANNER WILL RESULT IN LOSS

OF WARRANTY, AND CAN RESULT IN THE AND LOSS OF VEHICLE CONTROL, AND POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE.

- 10. Remove the tie rod end from the cross tube.
- 11. If the opposing tie rod end is being replaced repeat Steps 8 through 10.
- 12. Inspect the cross tube for dents, cracks, or thread damage, replace as necessary.

#### **ASSEMBLY**

1. Lubricate the new tie rod end threads with Anti-seize.

### NOTE

**⚠** WARNING

When installing the cross tube the thread direction of the tie rod ends are as follows:

- A right hand threaded tie rod end will be installed into the right side tie rod arm.
- A left hand threaded tie rod end will be installed into the left side tie rod arm.
- 2. Install the new tie rod end into the cross tube, leaving the same amount of threads exposed that were counted on the removed tie rod end.



34"-16 Tie Rod End Removal Tool



Cotter

1/2" Tie Rod End

 $68 \pm 7$  ft. lbs

 $(92 \pm 9 \text{ Nm})$ 

34" Castle Nut

Tightening Torque

95 ft. lbs. (129 Nm)

Steering Knuckle Arm

Tie Rod End


were counted on the removed tie rod end.



## **A** WARNING

THE THREADED PORTION OF THE TIE ROD END MUST EXTEND PAST THE SLOTS INTO THE TIE ROD CROSS TUBE, SEE FIGURE 9-44. FAILURE TO DO SO CAN CAUSE COMPONENT DAMAGE, LOSS OF VEHICLE CONTROL AND POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE.

#### FIGURE 9-44



#### 1/2" Tie Rod Clamp Bolt

It is critical to check the  $\frac{1}{2}$ " tie rod clamp bolt head location to verify the clamp fasteners have sufficient clearance away from the lower shock mount at full wheel cut. The fasteners must not contact the lower shock mount.

#### **Tie Rod Cross Tube Slots**

It is critical to have the threaded portion of the tie rod end extend past the slots in the tie rod cross tube.

½"Tie Rod Clamp Locknut Tightening Torque 68 ± 7 ft. lbs. (92 ± 9 Nm)

# **A** WARNING

IT IS CRITICAL TO CHECK THE TIE ROD CLAMP BOLT HEAD LOCATION TO VERIFY THE CLAMP FASTENERS HAVE SUFFICIENT CLEARANCE AWAY FROM THE LOWER SHOCK MOUNT AT FULL WHEEL CUT. THE FASTENERS MUST NOT CONTACT THE LOWER SHOCK MOUNT. FAILURE TO DO SO CAN CAUSE ONE OR MORE COMPONENTS TO FAIL CAUSING LOSS OF VEHICLE CONTROL AND POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE.

- 3. If replacing the opposing tie rod end is not necessary, it is critical that the ball and socket are free to rotate in the opposing tie rod end.
- 4. Replace the opposing tie rod end if necessary, by repeating Steps 1 and 2.
- 5. Install both tie rod ends into the cross tube and into the lower steering knuckles.
- 6. Tighten the tie rod to steering arm castle nuts to 95 ± 5 foot pounds torque, then rotate the castle nut to the next castle slot and install the cotter pin. DO NOT back off the castle nut to install cotter pin, see Figure 9-43.
- 7. Grease the tie rod ends with the specified lubricant, see lubrication specifications and procedure in the Preventive Maintenance section of this publication.
- 8. Set the toe, refer to the Toe Adjustment in the Alignment & Adjustments section of this publication.
- 9. Ensure alignment is acceptable, then tighten the tie rod to tie rod tube  $\frac{1}{2}$ " fasteners to  $\frac{1}{2}$  68 ± 7 foot pounds tightening torque, see Figure 9-44.
- 10. Remove the wheel chocks.

#### WHEEL END AND HYDRAULIC DISC BRAKE ASSEMBLIES AND COMPONENTS

#### **NOTE**

Wheel end hubs, seals, bearing cones, hub caps, as well as hydraulic disc brake assemblies and components are installed by Hendrickson for new production assembly but these components are not supplied by Hendrickson for aftermarket service purposes. For more information and assistance with service, maintenance and rebuild instructions on these items see the below listed component manufacturers. Refer to the Parts Lists section of this publication for additional information on such assemblies and components.

- Bosch technical and parts support 888.715.3616 or online www.boschautoparts.com
- DRiV Incorporated parts support 800.325.8886 or online www.drivparts.com
- SKF parts support 800.533.6563, e-mail: vsm.aftermarket.custsrv@skf.com, website: vehicleaftermarket.skf.com
- The Timken Company technical and parts support 866.984.6536 or online www.timken.com
- Webb Wheel Products technical and part support 800.633.3256 or online www.webbwheel.com

17730-356 49 Component Replacement



# SECTION 10 Troubleshooting Guide

# SOFTEK for Workhorse W56 Electric Step Vans

TROUBLESHOOTING GUIDE				
CONDITION	POSSIBLE CAUSE	CORRECTION		
Vibration or shimmy	Caster out of specification	Verify the rear air suspension(if equipped) is at the proper ride height if equipped, then adjust caster to specification.		
	Wheels and/or tires out of balance	Balance or replace the wheels and/or tires.		
of front axle during	Worn shock absorbers	Replace the shock absorbers.		
operation	Worn thrust washers (if equipped) and rear hanger clamps	Replace the thrust washers (if equipped) and rear hanger clamps.		
	Wheel bearing adjustment	Adjust the wheel bearing to the manufacturer's specifications.		
	Tires have incorrect air pressure	Adjust the tire pressure to vehicle manufacturer's specification.		
	Tires out of balance	Balance or replace the tires.		
	Incorrect toe setting	Adjust the toe-in to Hendrickson's specification.		
Excessive wear on tires or uneven tire tread	Incorrect steering arm geometry	Repair the steering system as necessary.		
wear	Worn kingpin bushings	Replace the kingpin bushings.		
	Excessive wheel bearing end play	Check the specified wheel nut torque, replace worn or damaged wheel bearings.		
	Wheel bearing adjustment	Adjust the wheel bearing to the manufacturers specifications.		
	Low pressure in the power steering system	Repair the power steering system.		
	Steering linkage needs lubrication	Lubricate the steering linkage.		
Vehicle is hard to steer	Steering knuckles are binding	Check the vertical clearance.		
	Incorrect steering arm geometry	Repair the steering system as necessary.		
	Caster out of specification	Adjust the caster to specification applicable.		
	Tie rod ends hard to move	Replace the tie rod ends.		
	Worn thrust bearing	Replace the thrust bearing.		
	Steering gear box internal problem	Perform the steering gear troubleshooting procedures per steering gear manufacturer's guidelines.		




# SOFTEK for Workhorse W56 Electric Step Vans

TROUBLESHOOTING GUIDE (CONTD.)				
CONDITION	POSSIBLE CAUSE	CORRECTION		
Bent or broken cross tube, tie rod end ball stud or tie rod end	Pump/gear relief valve pressure setting exceeds system specifications	Adjust the power steering system to manufacturer's specified pressure.		
	Steering gear poppets improperly set or malfunctioning	Check for proper operation or adjust poppets to vehicle manufacturer's specifications.		
NOTE: Damaged components	Axle stops improperly set	Set the axle stops to vehicle manufacturer's specifications.		
require replacement	Severe duty cycle service	Increase the frequency of inspection and lubrication intervals.		
	Drag link fasteners tightened past specified torque	Tighten the drag link fasteners to the specified torque.		
Worn or broken steering ball stud	Lack of lubrication or incorrect lubricant	Lubricate the linkage with specified lubricant.		
	Power steering stops out of adjustment	Adjust the steering stops to Hendrickson's specifications.		
_	Broken or worn leaf spring	Replace the leaf spring assembly.		
Suspension has harsh or bumpy ride	Front suspension overloaded	Redistribute the steer axle load.		
1,	Broken shock absorber	Replace the shock absorber.		
Restricted steering radius	Steering stops not adjusted correctly	Adjust the steering stops to achieve correct wheel cut.		
Vehicle leans	Suspension is not torqued correctly at installation	Perform a spring eye re-torque procedure, refer to the Alignment & Adjustment section of this publication.		
	Leaf spring broken	Replace the leaf spring assembly.		
	Excessive weight bias	Contact the vehicle manufacturer or Hendrickson Tech Services.		
	Caster out of specifications	Adjust the caster to specification applicable.		
Vehicle wanders	Incorrect toe setting	Adjust the toe to specification.		
	Air in the power steering system	Remove the air form the power steering systems.		



# Torque Specifications

# HENDRICKSON RECOMMENDED TORQUE VALUES Provided in Foot Pounds and in Newton Meters





### SOFTEK with STEERTEK NXT Axle for Workhorse W56 Electric Step Vans

HENDRICKSON RECOMMENDED TORQUE SPECIFICATIONS							
NO.	COMPONENT	FASTENERS		*TORQUE VALUE			
	COMPONENT	QTY.	SIZE	FOOT POUNDS	Nm		
1	Front Frame Hanger to Front Leaf Spring Eye	2	3/4"	330 ± 10	447 ± 14		
2	Rear Shackle Bracket to Shackle Plate	2	3/4"	370 ± 10	502 ± 14		
3	Rear Shackle Bracket to Spring Eye	2	9/4"				
4	Upper and Lower Shock Absorber Eye	2	5/8"	95 ± 5	129 ± 7		
	ENSURE CLAMP GROUP IS ALIGNED PROPERLY PRIOR TO TIGHTENING HARDWARE. FAILURE TO DO SO CAN CAUSE LOSS OF VEHICLE CONTROL, PROPERTY DAMAGE OR PERSONAL INJURY.						
5	Clamp Group Hardware	8	5/8"	180 ± 15	244 ± 20		
6	Rubber Axle Stop	2	_	Press Fit			
7	Knuckle Attachment Bolt (Socket Head Cap Screw)	4	5/8"	110 ± 10	149 ± 14		
8	Knuckle / Axle Wheel Stop Bolt	2	1/2"	50 ± 10	68 ± 14		
9	Tie Rod Tube to Tie Rod Ends	2	1/2"	68 ± 7	92 ± 9		
10	Tie Rod Ends to Lower Steering Knuckle	2	¾" Castle Nut	**95	**129		
11	Grease Cap Assembly, Upper and Lower	4	1/2"	60 ± 10	81 ± 14		
12	Grease Zerk	2		***	***		

<sup>•</sup> All hardware ¼" and greater is Grade 8 with no additional lubrication. Frame mount hardware in most cases are Huck style fasteners supplied by the vehicle manufacturer.

# **NOTE:** \* All hardware information in the matrix denotes recommended torques for fasteners originally supplied by Hendrickson. If non Hendrickson fasteners are used, follow torque specifications listed in the vehicle manufacturer's service manual. Hendrickson is not responsible for maintaining vehicle manufacturer's torque values.


- \*\* Torque to 95 foot pounds (129 Nm), advance castle nut to next hex face to install the cotter pin. **DO NOT** back off the nut for cotter pin installation.
- \*\*\* Thread until it bottoms out to within 1.2 mm maximum gap between hex and steering arm surface.

17730-356 53 Torque Specifications



## Wheel End Assembly with Hydraulic Disc Brakes

# HENDRICKSON RECOMMENDED TORQUE VALUES Provided in Foot Pounds and in Newton Meters



## SOFTEK with STEERTEK NXT Axle for Workhorse W56 Electric Step Vans Hydraulic Disc Brake Assembly

HENDRICKSON RECOMMENDED TORQUE SPECIFICATIONS				
NO.	COMPONENT	FASTENERS	*TORQUE VALUE	
		QTY.	FOOT POUNDS	Nm
1	Hub Cap Fasteners	8	14 ± 2	19 ± 3
2	Brake Mounting Fasteners – Length 2½"	8	110 ± 10	150 ± 14
3	Brake Mounting Fasteners – Length 1½"	8	110 ± 10	150 ± 14

NOTE: \* All hardware information in the matrix denotes recommended torques for fasteners originally supplied by Hendrickson. If non Hendrickson fasteners are used, follow torque specifications listed in the vehicle or brake component manufacturer's service manual, see Parts List section for brake supplier. Hendrickson is not responsible for maintaining vehicle manufacturer's torque values.



# Front Wheel Alignment Specifications

#### **SOFTEK for Workhorse W56 Electric Step Vans**

FRONT SYSTEM SUSPENSION ALIGNMENT SPECIFICATION				
CAMPEDI	DESIGN SPECIFICATION	RANGE		
CAMBER <sup>1</sup>		MINIMUM	MAXIMUM	
LEFT	0.00° ± 1.0°	-1.0°	+1.0°	
RIGHT	- 0.25° ± 1.0°	-1.25°	+0.75°	
CROSS	Max 2.0°	_	_	

#### **CAMBER NOTES:**

<sup>1</sup> The camber angle is not adjustable. Do not bend axle or otherwise try to adjust camber. If found out of specification, notify Hendrickson Tech Services for further information.

CASTER <sup>1,2</sup>	DESIGN SPECIFICATION	RANGE		
		MINIMUM	MAXIMUM	
LEFT	3.0° ± 1°	+2.0°	+4.0°	
RIGHT	3.0° ± 1°	+2.0°	+4.0°	
CROSS <sup>3</sup>	Max 1.0°	_	_	

#### **CASTER NOTES:**

- <sup>1</sup> Caster is to be measured with the vehicle at the rated load for mechanical suspension systems. Ensure the rear air suspension (if equipped) ride height is within specification prior to performing a caster measurement or adjustment.
- <sup>2</sup> In most cases actual vehicle caster is defined with the frame rails at zero slope. Refer to the vehicle manufacturer's specifications for correct frame rail slope. (Both the alignment surface and the vehicle's frame rails should be level during execution of alignment procedures). For vehicles with a positive frame rake (higher in rear) add the frame slope (in degrees) to the caster reading to determine true vehicle caster.
- The cross caster angle is not adjustable DO NOT bend axle or otherwise try to adjust cross caster. If caster measurement falls outside of the specification, notify Hendrickson Tech Services for further information. Changes to caster can be attained by using caster shims provided by the chassis or body manufacturer. Caster shims must match, side to side to reduce uneven loading to the suspension components. The use of two (2) different angle caster shims will not correct cross caster.

Example of caster adjustment:  $2.5^{\circ}$  Right Hand /  $3^{\circ}$  Left Hand, would require one, 1.0 shim on each side to increase caster and achieve  $3.50^{\circ}$  Right Hand /  $4.00^{\circ}$  Left Hand, which is in specification. **DO NOT** attempt to use uneven shims.

#### Hendrickson recommends following practices:

	DESIGN SPECIFICATION <sup>1</sup>	RAI	RANGE		
		MINIMUM	MAXIMUM		
TOTAL TOE	1/16" ± 1/32" (0.06" ± 0.03")	1/32" (0.03")	3/32" (0.09")		

#### **TOE-IN NOTES:**

<sup>1</sup> Toe-in is to be set and adjusted in the normal vehicle unladed configuration. Actual vehicle curb weight on the ground. Toe should be checked at the tires front and rear tread center, at a distance above ground equal to the tire's rolling radius.



# SECTION 13 Reference Material

This technical publication covers Hendrickson Truck Commercial Vehicle suspension's recommended procedures for our parts/products. Other components play a major role in overall performance and Hendrickson recommends you follow the specific vehicle manufacturer's recommendation for care and maintenance. Some recommended procedures have been developed by TMC and Hendrickson supports these recommendations.

To obtain copies of TMC's Recommended Practices Manual at:

TMC / ATA Headquarters 950 North Glebe Road, Suite 210 Arlington, VA 22203-4181 Phone: 703-838-1763 website: tmc.trucking.org

online ordering: atabusinessolutions.com/Shopping

Actual product performance may vary depending upon vehicle configuration, operation, service and other factors.

All applications must comply with applicable Hendrickson specifications and must be approved by the respective vehicle manufacturer with the vehicle in its original, as-built configuration. Contact Hendrickson for additional details regarding specifications, applications, capacities, and operation, service and maintenance instructions.

Call Hendrickson at 630.910.2800 or 855.RIDERED (855.743.3733) for additional information.



www.hendrickson-intl.com