



H TECHNICAL PROCEDURE

AIRTEK® • SOFTEK® • STEERTEK for International Truck Vehicles

SUBJECT: Service Instructions

LIT NO: 17730-252

DATE: December 2008

REVISION: D

TABLE OF CONTENTS

Section 1	Introduction	2	Section 9	Component Replacement (Cont.)	
Section 2	Product Description	3		AIRTEK (NEC) Rear Spring Hanger and Thrust Washers	55
Section 3	Important Safety Notice	6		SOFTEK Shackle Plate	56
Section 4	Parts Lists			AIRTEK Leaf Spring Assembly	57
	AIRTEK (NEC)	10		SOFTEK Monoleaf Leaf Spring Assembly	60
	AIRTEK (PEC)	12		AIRTEK Rear Spring Mount	62
	SOFTEK Monoleaf	16		Front Leaf Spring Eye Bushing	65
	STEERTEK for International 2-Leaf	18		AIRTEK Bottom Axle Wrap	65
Section 5	Special Tools	20		SOFTEK/STEERTEK Bottom Axle Wrap	66
Section 6	Towing Procedures	21		AIRTEK Top Axle Wrap (in chassis)	67
Section 7	Preventive Maintenance			SOFTEK-STEERTEK Top Axle Wrap (in chassis)	71
	Component Inspection	24		AIRTEK Front Axle Assembly	74
	Lubrication Intervals	25		SOFTEK Front Axle Assembly	75
	Kingpin Lubrication	25		STEERTEK Axle Removal	76
	Tie Rod End Lubrication	26		STEERTEK Axle (removed from chassis)	77
	Tie Rod End Inspection	27		Steering Knuckle Disassembly	81
	Clamp Group Re-torque Interval	29		Kingpin Preparation & Measurement	82
	Tire Inspection	30		Kingpin Bushing Removal	84
	Shock Absorber Inspection	32		Steering Knuckle Bore Measurement	85
	AIRTEK Thrust Washer Inspection	34		Kingpin Bushing Installation	85
	Kingpin Bushing Inspection	35		Kingpin Bushing Reaming	86
	Steering Knuckle Inspection	36		Kingpin Seal Installation	87
	Axle Wrap Liner Inspection	36		Steering Knuckle Assembly	88
Section 8	Alignment & Adjustments		Section 10	AIRTEK Plumbing Diagrams	
	Alignment Definitions	37		Single Height Control Valve	94
	Inspection Prior to Alignment	40		Dual Height Control Valves	95
	Front Wheel Alignment	41	Section 11	Tightening Torque Specifications	
	AIRTEK Single Ride Height Verification	42		AIRTEK	96
	AIRTEK Dual Ride Height Verification	44		SOFTEK	98
	AIRTEK Height Control Valve Test	47	Section 12	Troubleshooting Guide	
	Steering Stop	48		AIRTEK	100
	Toe Setting	48		SOFTEK	102
Section 9	Component Replacement		Section 13	Alignment Specifications	103
	Fasteners	50	Section 14	Reference Material	104
	AIRTEK Height Control Valve	50	Section 15	Technical Procedure Publication Quiz	105
	AIRTEK Air Spring	51			
	Shock Absorber	53			
	AIRTEK Belly Band	54			