

H GENUINE PARTS

Air Springs



Hendrickson Air Springs are integral parts on our line of truck and tractor air suspensions, providing driver comfort and optimum performance. Regular suspension inspections are necessary to help ensure maximum ride quality and handling. Replacing Hendrickson air springs with non-genuine springs can have a negative impact on suspension performance.

To provide high end user satisfaction and peak system performance, Hendrickson supplies the same genuine components for service as were installed in the original suspensions — with the same design, construction, performance and durability.

- Hendrickson air springs are designed and tuned specifically for approved applications.
- Ride quality and performance are key factors when designing the internal makeup of Hendrickson air springs. A low natural frequency is achieved through proprietary piston and bump stop components. Using non-genuine air springs can alter the weight rating and performance of Hendrickson suspensions.
- Hendrickson air springs undergo advanced design and testing processes to provide enhanced suspension ride, handling and performance.
- Look for the Hendrickson name and logo on the air spring to guarantee you are getting genuine Hendrickson service parts.



Contact Hendrickson toll-free at **1-866-755-5968**

H GENUINE PARTS

www.hendrickson-initl.com



H HENDRICKSON
The World Rides On Us®

GENUINE PARTS

Air Springs



Part No.	Model	Capacity/Other	Comments
AIRTEK® • IFS™			
66349-002L	AIRTEK • Volvo • Mack	12K/12.5K	Vehicles built 03/05–06/07 equipped w/Dual Height Control Valves MUST use air spring with support plate service kit number 60961-182.
66349-002L	AIRTEK • Spartan	10.5K/12K	
60716-002L	AIRTEK • Volvo • Mack	13.2K/14.6K	
59823-002	AIRTEK • Freightliner • Western Star		
65790-002L	AIRTEK • International Truck		
	AIRTEK • Spartan	12.6K/14.6K	
68348-002L	IFS • Spartan		

HTB™

60977-002	HTB LT • International Truck		
60977-002	HTB 210 • Spartan		Mid Engine, Rear Engine, Drive Tag

COMFORT AIR®

60925-002	COMFORT AIR • Blue Bird		
60929-002	COMFORT AIR • Blue Bird		Front Engine
65086-002	COMFORT AIR • Hino		

HAS™ SERIES

56917-002L	HAS	150L/190L/210L/230L 400L/402L	
59055-002		190	Air spring only, with metric studs
57122-002L		190/210/230/400/402/460	
58520-002L		210/230/400/402/460/40LH	
50899-002L		210	
59861-002		40LH	
50898-002L		Low Profile 120L	
57920-002L		Low Profile 120L	Air spring only
57965-002L		Low Profile 210L/230L	
58983-002		Low Profile 150/210L/230L	
59031-002			Air spring only
49048-002L			
64489-002			
64651-002			
50405-002L	HA		
64917-002	MAXAIR/AL-405		
58786-002	MAXAIR/AL-405		



PARASTEER™

58484-002L	PARASTEER • Blue Bird	TCRE/CSRE, TCFE/CSFE/HDRE, QBRE/C4RE	
59601-002L		TSFE/CIFE	Flat Floor

AR2™

65455-002	AR2	400/460	Forward
65652-002		400/460	Rear
65998-002		520	

PRIMAAX® EX • FIREMAAX® EX

Ride Height 8½"-10"

67063-002L	PRIMAAX EX	232/462/692	
67392-002	FIREMAAX EX	242/482	
67234-002	PRIMAAX EX • International Truck	232/462/692	Includes upper air spring bracket and fasteners
60271-002L	PRIMAAX • Type A	230/460/690	
65183-002	FIREMAAX • Type A	240/480	
67247-002	PRIMAAX EX	262/522/782	Includes support plate, upper air spring bracket, and fasteners
68056-002	FIREMAAX EX	272/542	Includes upper air spring frame bracket and fasteners
65282-002	PRIMAAX/FIREMAAX • Type A	260/520/780 • 270/540	Air spring only
66255-002	PRIMAAX • Type A	260/520/780	Includes upper air spring bracket and fasteners

Ride Height 12½" 14¾" 15½"

67391-002	PRIMAAX EX/FIREMAAX EX	232/462/692 • 242/482	Air spring only
65032-002	PRIMAAX/FIREMAAX • Type A	230/460/692 • 240/480	



www.hendrickson-intl.com



Truck Systems Group
800 South Frontage Road
Woodridge, IL 60517-4904 USA

630.910.2800
Fax 630.910.2899