## 

DO NOT REMOVE PIVOT CONNECTION HARDWARE OR END-CAP HARDWARE WHEN COIL SPRING IS UNDER TENSION. Doing so could cause unexpected, sudden and violent movement of suspension parts that can result in serious injury or property damage. Refer to Hendrickson publication L765, VANTRAAX<sup>®</sup> HRRNT 40K / HRRT 50K Maintenance Procedures, for complete coil spring tension releasing instructions.

Trailer Suspension Systems 2070 Industrial Place SE Canton, OH 44707-2600 USA 800.455.0043 330.489.0045 Fax 800.696.4416

## HENDRICKSON Trailer Suspension Systems 250 Chryster Drive, Unit #3 Brampton, ON L6S 6B6 Car

250 Chrysler Drive, Unit #3 Brampton, ON L6S 6B6 Canada 905.789.1030 Fax 905.789.1033

The Boler Company. Copyright ©2004

All Rights Reserved.

L864 03-04 Printed in USA.

## NOTES

www.hendrickson-infl.com

- 1. Shown actual size.
- 2. Use one of the following adhesives:
  - Fasson Tire Label II (TL2). Hot melt rubber on latex impregnated paper with barrier coating on adhesive side.
  - b. P1480.
- 3. Finished decal height to be **no more** than 3.1875 inches.